SAMSUNG

Samsung GALAXY Tab 7.7 GT-P6810

user manual

Using this manual

Congratulations on your purchase of the Samsung device. This powerful, "go anywhere" device, puts the best of the web and mobile computing at your fingertips in a lightweight, highly versatile platform that fits your active lifestyle. Built on the Google Android operating system, the device gives you access to thousands of useful and entertaining applications to enrich your mobile web experience.

With integrated wireless access and a responsive touch screen, you can read books and newspapers on the go; stay up-to-date on the latest news, sports, and weather; manage your multimedia and business files; and browse the web for maps, business locations, and more.

Read me first

- Please read all safety precautions and this manual carefully before using your device to ensure safe and proper use.
- The descriptions in this manual are based on the default settings of your device.
- Images and screenshots used in this user manual may differ in appearance from the actual product.
- Content in this user manual may differ from the product, or from software provided by service providers or carriers, and is subject to change without prior notice. Refer to www.samsung.com/hk for the latest version of the user manual.
- Available features and additional services may vary by device, software, or service provider.

- Formatting and delivery of this user manual is based on Google Android operating systems and may vary depending on the user's operating system.
- Applications and their functions may vary by country, region, or hardware specifications. Samsung is not liable for performance issues caused by third-party applications.
- Samsung is not liable for performance issues or incompatibilities caused by user editing of registry settings.
- You may upgrade your device's software by accessing www.samsung.com/hk.
- Software, sound sources, wallpapers, images, and other contents provided in this device are licenced for limited use between Samsung and their respective owners. Extracting and using these materials for commercial or other purposes is an infringement of copyright laws. Samsung is not liable for such copyright infringement by the user.
- Please keep this manual for future reference.

Instructional icons

Before you start, familiarise yourself with the icons you will see in this manual:

Warning—situations that could cause injury to yourself or others

Caution—situations that could cause damage to your device or other equipment

Note—notes, usage tips, or additional information

► **Refer to**—pages with related information; for example: ► p. 12 (represents "see page 12")

→ **Followed by**—the order of options or menus you must select to perform a step; for example: Open the application list and select **Settings** → **Wireless and networks** (represents **Settings**, followed by **Wireless and networks**)

Copyright

Copyright © 2011 Samsung Electronics

This user manual is protected under international copyright laws.

No part of this user manual may be reproduced, distributed, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or storing in any information storage and retrieval system, without the prior written permission of Samsung Electronics.

Trademarks

- SAMSUNG and the SAMSUNG logo are registered trademarks of Samsung Electronics.
- The Android logo, Google Search™, Google Maps™, Google Mail™, YouTube™, Android Market™, and Google Talk™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide.
- Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

- Windows Media Player® is a registered trademark of Microsoft Corporation.
- Wi-Fi®, Wi-Fi Protected Setup™, Wi-Fi Direct™, Wi-Fi CERTIFIED™, and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- DivX®, DivX Certified®, and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under licence.
- All other trademarks and copyrights are the property of their respective owners.

ABOUT DIVX VIDEO

DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX videos.

DivX Certified® to play DivX® video up to HD 720p, including premium content

ABOUT DIVX VIDEO-ON-DEMAND

This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.

Contents

Assembling 10

Unpack 10
Charge the battery 11
Insert a memory card (optional) 13

Getting started 16

Turn your device on and off 16
Get to know your device 18
Use the touch screen 23
Get to know the Home screen 25
Access applications 29
Customise your device 30
Enter text 33

Communication 40

Google Mail 40
Email 41
Talk 44
Social Hub 45

Web 46

Browser 46
Pulse 52
Market 53
YouTube 54
Maps 55
Latitude 56

Places 57
Navigation 58
Readers Hub 59
Samsung Apps 59

Entertainment 60
Music player 60
Camera 62
Video player 72
Gallery 73
Photo editor 75
Video maker 76
Game Hub 78

Personal information 79
Contacts 79
Calendar 82
Memo 84

Connectivity 85
PC connections 85
Wi-Fi 87
Wi-Fi Direct 88
Bluetooth 89
AllShare 91
GPS 93
VPN connections 95

Tools 97
Alarm 97
Calculator 98
Downloads 98
eBook 98
Google Search 100
My files 100
Pen memo 102
Polaris Office 103
Task Manager 105
Voice Search 105
World clock 106

Settings 107
Access the Settings menu 107
Wireless and networks 107
Sound 109
Screen 109
Power saving mode 110
Location and security 111
Applications 113
Accounts and sync 114
Motion 114
Privacy 114
Storage 115
Language and input 115
Accessibility 120

Date and time 121
About device 121

Troubleshooting 122

Safety precautions 125

Assembling

Unpack

Check your product box for the following items:

- Device
- Quick start guide

Use only Samsung-approved software. Pirated or illegal software may cause damage or malfunctions that are not covered by your manufacturer's warranty.

- The items supplied with your device and available accessories may vary depending on your region or service provider.
- You can purchase additional accessories from your local Samsung dealer.
- The supplied accessories perform best for your device.
- Accessories other than the supplied ones may not be compatible with your device.

Charge the battery

Your device has a built-in battery. Before using the device for the first time, you must charge the battery.

- Use only Samsung-approved chargers. Unauthorised chargers can cause batteries to explode or damage your device.
- The back cover of your device is made of metal. Use only the ETA-P12X / ETA-P11JBE series charger with your device to prevent electric shock.

- Charge the battery only with a charger. You cannot charge the battery with the USB cable.
- When your battery is low, the device will emit a warning tone and display a low battery message. The battery icon will also be empty. If the battery level becomes too low, the device will automatically power off. Recharge your battery to continue using your device.
- If the battery is completely discharged, you cannot turn on the device, even with the travel adapter connected. Allow a depleted battery to charge for a few minutes before you try to turn on the device.

1 Connect the AC plug to the charging head, and then plug the small end of the travel adapter into the multifunction jack.



Connecting the travel adapter improperly may cause serious damage to the device. Any damage caused by misuse is not covered by the warranty.

2 Plug the large end of the travel adapter into a power outlet.

- You can use the device while it is charging, but it may take longer to fully charge the battery.
- While the device is charging, the touch screen may not function due to an unstable power supply. If this happens, unplug the travel adapter from the device.
- While charging, the device may heat up. This is normal and should not affect your device's lifespan or performance.
- If your device is not charging properly, bring your device and the charger to a Samsung Service Centre.

3 When the battery is fully charged, first unplug the travel adapter from the device and then from the power outlet.

To save energy, unplug the travel adapter when not in use. The travel adapter does not have a power switch, so you must unplug the travel adapter from the outlet when not in use to avoid wasting power. The travel adapter should remain close to the socket when in use.

Insert a memory card (optional)

To store additional files, you must insert a memory card. Your device accepts microSD™ or microSDHC™ memory cards with maximum capacities of 32 GB (depending on memory card manufacturer and type).

Samsung uses approved industry standards for memory cards, but some brands may not be fully compatible with your device. Using an incompatible memory card may damage your device or the memory card and can corrupt data stored on the card.

- Your device supports only the FAT file structure for memory cards. If you insert a card formatted with a different file structure, your device will ask you to reformat the memory card.
- Frequent writing and erasing of data will shorten the lifespan of memory cards.
- When you insert a memory card in your device, the file directory of the memory card will appear in the extStorages folder under the internal memory.

1 Open the cover of the memory card slot.

2 Insert a memory card with the gold-coloured contacts facing down.



3 Push the memory card in the memory card slot until it locks in place.

4 Close the memory card cover.

› Remove the memory card

Before removing a memory card, first unmount it for safe removal.

1 Open the application list and select **Settings** → **Storage** → **Unmount SD card**.

2 Open the memory card cover.

3 Push the memory card gently until it disengages from the device.

4 Remove the memory card.

Do not remove a memory card while the device is transferring or accessing information, as this could result in loss of data or damage to the memory card or device.

› Format the memory card

Formatting your memory card on a PC may cause incompatibilities with your device. Format the memory card only on the device.

Open the application list and select **Settings** → **Storage** → **Erase SD card** → **Format SD card** → **Erase everything**.

Before formatting the memory card, remember to make backup copies of all important data stored on your device. The manufacturer's warranty does not cover loss of data resulting from user actions.

Getting started

Turn your device on and off

To turn on your device, press and hold the Power key. If you turn on your device for the first time, follow the on-screen instructions to set up your device.

To turn off your device, press and hold the Power key and select **Power off** → **OK**.

› Set up your Google account

To use applications provided by Google, such as Google Mail, Android Market, and Google Maps, you must have a Google account. If you have not signed in to Google during the initial setup, set up your Google account as follows.

1. Open the application list and select **Settings** → **Accounts and sync**.
2. Select **Add account** → **Google Accounts**.
3. Enter your email address and password for your Google account and select **Sign in**.
   To create a Google account, select **Create account**.
4. Follow the on-screen instructions.

› Use the quick settings with the notifications panel

From the Home screen or while using an application, select the right side of the system bar, and then select an option on the notifications panel.

You can view the device's current status and use the following options:

- **Wi-Fi**: Activate or deactivate the Wi-Fi feature.
- **Notification**: Set the device to alert you for various events.
- **GPS**: Activate or deactivate the GPS feature.
- **Sound**/**Vibration**: Activate or deactivate Vibration mode.
- **Auto Rotation**: Activate or deactivate the auto rotation.
- **Bluetooth**: Activate or deactivate the Bluetooth wireless connection feature.
- **Airplane mode**: Activate or deactivate Airplane mode.

You can also adjust the display brightness or access the settings menu.

Available options may vary depending on your region or service provider.

Get to know your device

› Device layout

Front view of the device



Number	Function
1	Earpiece
2	Proximity sensor
3	Light sensor
4	Speaker
5	Mouthpiece

Number	Function
6	Front camera lens
7	Power/Reset/Lock key
8	Volume key
9	Multifunction jack

Back view of the device



Number	Function
1[1]	Mouthpiece
2	Rear camera lens
3	Flashbulb

1. Active only when you use the speakerphone feature or record videos.

Number	Function
4[2]	Headset jack
5[3]	GPS antenna
6	Memory card slot

› Keys

Key		Function
	Power/ Reset[4]/ Lock	Turn on the device (press and hold); Access the quick menus (press and hold); Reset the device (press and hold for 10-15 seconds); Lock the touch screen.
	Volume	Adjust the device's volume.

2. Connecting a headset to your device improperly can damage the headset jack or the headset.
3. Do not touch or cover the antenna area with your hands or other objects while using the GPS functions.
4. If your device has fatal errors or hang-ups, or freezes, you may need to reset the device to regain functionality.

› Indicator icons

Icons shown on the display may vary depending on your region or service provider.

Icon	Definition
	Open Wi-Fi APs available
	Wi-Fi connected
	Bluetooth activated
	Receiving GPS data
	Synchronised with the web
	Data downloaded successfully
	Uploading data
	Downloading data
	Connected to PC
	Power saving mode activated
	USB tethering activated
	USB debugging activated
	Wi-Fi tethering activated

Icon	Definition
	New email message
	New Google Mail
	Alarm activated
	Event notification
	Flight mode activated
	Music playback in progress
	Error occurred or caution required
[1]	Battery power level
	Unable to charge
	Current time

1. If you use a charger that is not approved by Samsung, this indicator will not appear.

Use the touch screen

Your device's touch screen lets you easily select items or perform functions. Learn basic actions to use the touch screen.

- To avoid scratching the touch screen, do not use sharp tools.
- Do not allow the touch screen to come into contact with other electrical devices. Electrostatic discharges can cause the touch screen to malfunction.
- Do not allow the touch screen to come into contact with water. The touch screen may malfunction in humid conditions or when exposed to water.

- For optimal use of the touch screen, remove the screen protection film before using your device.
- Your touch screen has a layer that detects small electrical charges emitted by the human body. For best performance, touch the screen with your fingertip. The touch screen will not react to touches of sharp tools, such as a stylus or pen.

You can control your touch screen with the following actions:

- Touch: To act on items on the screen, such as applications or widgets, to type letters and symbols using the on-screen keyboard, or to press on-screen keys, you simply touch them with your finger.
- Drag: Touch and hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. For example, you drag items on the Home screen to reposition them. ► p. 27

- Touch and hold: Touch and hold an item on the screen by touching it but not lifting your finger until an action occurs.
- Drag and drop: Touch and hold your finger on an item, and then drag your finger to move the item.
- Swipe or slide: To swipe or slide, you quickly move your finger across the surface of the screen, without pausing when you first touch it. For example, you slide the Home screen left or right to view the other parts, and in some Calendar views you slide to view earlier or later periods.
- Double-touch: Touch quickly twice on a web page, map, or other screen to zoom. For example, you double-touch a section of a web page in Browser to zoom that section to fit the width of the screen. Double-touching after pinching to zoom in some applications reflows a column of text to fit the width of the screen.
- Pinch: In some applications, such as Maps, Browser, and Gallery, you can zoom in and out by placing two fingers on the screen at once and pinching them together to zoom out or spreading them apart to zoom in.

› Rotate the touch screen

Your device has a built-in motion sensor that detects its orientation. If you rotate the device, the interface will automatically rotate according to the orientation.

To set the interface to keep the orientation, select the right side of the system bar and then select **Auto Rotation** on the notifications panel.

› Lock or unlock the touch screen

When you do not use the device for a specified period, your device turns off the touch screen and automatically locks the touch screen to prevent any unwanted device operations. To manually lock the touch screen, press the Power key.

To unlock, turn on the screen by pressing the Power key, touch anywhere on the screen, and then drag outside of the large circle. When you unlock the screen, you can see the last screen you were viewing.

You can activate the screen lock feature to prevent others from using or accessing your personal data and information saved in your device. ► p. 31

Get to know the Home screen

When the device is in Idle mode, you will see the Home screen. From the Home screen, you can view indicator icons, widgets, shortcuts to applications, and other items. Scroll left or right to a panel of the Home screen.



The above screen may differ depending on your region or service provider.

Number	Function
1	Search for applications and files in your device and specific data on the web with the Google Search widget.
2	Select a dot at the top of the screen to move directly to the corresponding screen.
3	Customise the Home screen.
4	Access the application list.
5	System bar (See the following section).

System bar

From the system bar, you can quickly navigate screens, access applications, view system information, and more.



Number	Function
1	Capture the current screen and open the drawing pad; Capture the current screen (touch and hold).
2	Return to the previous screen, option, or step.
3	Return to the Home screen; Access the task manager (touch and hold).

Number	Function
❹	Open the list of recent applications; Access the application list (touch and hold).
❺	Display indicator icons and your device's current status; Open the notifications panel.
❻	Open the mini apps panel.

› Add items to the Home screen

You can customise the Home screen by adding shortcuts to applications or items in applications, widgets, or folders.

To add an item to the Home screen,

1. From the Home screen, select ⊞.
2. Select an item category.
   - **Widgets**: Add widgets. Widgets are small applications that provide convenient functions and information.
   - **App Shortcuts**: Add shortcuts to applications.
   - **Wallpaper**: Set a background image.
   - **More**: Add shortcuts to items, such as bookmarks, contacts, and maps.
   - **Folders**: Create a new folder or add folders for your contacts.
3. Select an item to add to the Home screen.

› Move items on the Home screen

1. Touch and hold an item to move until the Home screen grid appears.
2. Drag the item to the location you want and lift your finger.

› Remove items from the Home screen

1 Touch and hold an item to remove.
The trash bin appears at the top right of the Home screen.

2 Drag the item to the trash bin.

3 When the item turns red, release the item.

› Add a shortcut to an application

1 From the application list, touch and hold an application icon and drag it to a Home screen panel at the bottom of the screen.
The shortcut icon for the application is added to the Home screen.

2 Move the icon to the location you want or move it to another panel of the Home screen.

› Select a wallpaper for the Home screen

1 From the Home screen, select → **Wallpaper**.

2 Select an image folder.
If you selected **Wallpaper**, select **Home screen wallpaper**.

3 If you selected a live wallpaper, select **Set wallpaper**.
If you selected an image from Gallery, move or resize the rectangle to select a portion of the image, and then select **OK**.

Samsung is not responsible for any use of default images or wallpapers provided on your device.

Access applications

1 From the Home screen, select **Apps** to access the application list.

2 Select **All** → an application.
- To view downloaded applications, select **Downloaded**.
- To view the frequently-used applications, select **Frequent**.

3 Select ↩ to return to the previous screen; Select ⌂ to return to the Home screen.

› Access recent applications

1 Select ▭ to view the applications you have accessed recently.

2 Select an application.

› Use the task manager

Your device is a multitasking device. It can run more than one application at the same time. However, multitasking may cause hang-ups, freezing, memory problems, or additional power consumption. To avoid these problems, end unnecessary programs using the task manager.

1 Tap and hold ⌂.

2 To close an application, select **End**.
To close all active applications, select **End all**.

Customise your device

Get more from your device by customising it to match your preferences.

› Change the language of the display

1. Open the application list and select **Settings** → **Language and input** → **Select language**.
2. Select a language you want.

› Set the current time and date

1. Open the application list and select **Settings** → **Date and time**.
2. Select your time zone, set the time and date, and change other options.

› Turn the touch tone on or off

Open the application list and select **Settings** → **Sound** → **Audible selection**.

› Adjust the device's volume

1. Press the Volume key up or down.
2. Select and drag to adjust the volume level for media sounds, notifications, and alarm sounds.

› Switch to Silent mode

To mute or unmute your device, do one of the following:

- Open the notifications panel at the right side of the system bar and select **Sound**.
- Press and hold the Power key and select **Silent mode**.

You can set the device to alert you to various events in Silent mode. Open the application list and select **Settings** → **Sound** → **Vibrate** → **Always** or **Only in Silent mode**. When you switch to Silent mode, **Vibration** will appear in place of **Silent** on the notifications panel.

› Activate animation for switching windows

You can set a transition effect between windows while using the device.

1. Open the application list and select **Settings** → **Screen** → **Animation**.
2. Select an animation option.

› Adjust the brightness of the display

1. Open the application list and select **Settings** → **Screen** → **Brightness**.
2. Clear the check box next to **Automatic brightness**.
3. Drag the slider to adjust the level of brightness.
4. Select **OK**.

The brightness level of the display will affect how quickly the device consumes battery power.

› Set a screen lock

You can lock the touch screen with an unlock pattern or password to prevent unauthorised people from using the device without your permission.

- Once you set a screen lock, your device will require an unlock code each time you turn it on or unlock the touch screen.
- If you forget your PIN or password, bring your device to a Samsung Service Centre to reset it.
- Samsung is not responsible for any loss of security codes or private information or other damages caused by illegal software.

Set an unlock pattern

1. Open the application list and select **Settings** → **Location and security** → **Configure lock screen** → **Pattern**.
2. See the on-screen instructions and example patterns and select **Next**.
3. Draw a pattern by dragging your finger to connect at least 4 dots and select **Continue**.
4. Draw the pattern again to confirm and select **Confirm**.

Set an unlock PIN code

1. Open the application list and select **Settings** → **Location and security** → **Configure lock screen** → **PIN**.
2. Enter a new PIN (numeric) and select **Continue**.
3. Enter the PIN again and select **OK**.

Set an unlock password

1. Open the application list and select **Settings** → **Location and security** → **Configure lock screen** → **Password**.
2. Enter a new password (alphanumeric) and select **Continue**.
3. Enter the password again and select **OK**.

Enter text

You can enter text by selecting characters on the virtual keypad or by inputting handwriting on the screen.

You cannot enter text in some languages. To enter text, you should change the writing language to one of the supported languages. ► p. 115

› Change the keyboard type

You can change the keyboard type. Select on the system bar and select a keyboard type (Android keyboard, DioPen Chinese IME, Samsung keypad, or Swype).

You can also enter text with your voice. Select and a voice input option, according to the language you want to use.

› Enter text using the Android keyboard

Enter text by selecting alphanumeric keys and you can use the following keys:



Number	Function
1	Move the cursor to the next text input field.
2	Switch between Symbol/Number mode and ABC mode.
3	Change case.
4	Change the input language or access the keypad settings; Change the keyboard type (touch and hold).

Number	Function
❺	Insert an emoticon; Open the emoticon list (touch and hold).
❻	Clear your input.
❼	Start a new line.
❽	Enter text by voice. This feature may be unavailable depending on the selected input language.
❾	Insert a space; Insert a full stop (double-touch).

› Enter text using the DioPen Chinese IME keypad

1 Select ⚙ → **Keypad types** and select a text input method.

You can select QWERTY keypad or handwriting input methods.

You can also scroll left or right on the keypad to switch between text input methods.

2 Enter text by selecting alphanumeric keys or writing on the screen.

You can use the following keys:



Number	Function
❶	Move the cursor to the next text input field.
❷	Change case.
❸	Access the keypad settings; Change the keyboard type (touch and hold).
❹	Switch between Number/Symbol mode and ABC mode.
❺	Change the input language.
❻	Insert a space.
❼	Clear your input.
❽	Start a new line.
❾	Attach an item.
❿	Enter text by voice. This feature may be unavailable depending on the selected input language.
⓫	Insert an emoticon; Open the emoticon list (touch and hold).
⓬	Insert a full stop; Open the symbol panel (touch and hold).

In the handwriting mode, you can use the following gestures:

Function	Gesture
Space	⟵ (English), ⟵ (Chinese)
Enter	⟵
Backspace	⟵

› Enter text using the Samsung keypad

Enter text by selecting alphanumeric keys and you can use the following keys:



Number	Function
1	Minimise the virtual keypad.
2	Move the cursor to the next text input field.
3	Change case.
4	Switch between Number/Symbol mode and ABC mode.
5	Insert an emoticon; Open the emoticon list (touch and hold).
6	Clear your input.
7	Start a new line.
8	Attach an item.
9	Switch to the handwriting keypad.
10	Insert a space.

You can activate XT9 predictive text mode by selecting → → **XT9**. When you enter the first two letters of a word, the alternate word list appears.

You can use a variety of gestures in Handwriting mode to edit text. For more information about gestures, select → **Handwriting settings** → **Gesture guide**.

› Enter text using the Swype keypad

1 Select the first character of a word and drag your finger to the second character without releasing the finger from the screen.

2 Continue until you have finished the word.



3 Release the finger on the last character.

4 When the word displays correctly, select ⎵ to insert a space. If the correct word does not display, select an alternative word from the list that appears.

5 Repeat steps 1-4 to complete your text.

- You can also touch the keys to enter text.
- You can touch and hold a key to enter characters on the upper half of the key. When you touch and hold a key until the character list appears, you can enter special characters and symbols.

You can also use the following keys:



Number	Function
❶	Change the input language.
❷	Move the cursor to the next text input field.
❸	Change case.
❹	Access the swype tip screen; Open the help information (touch and hold).
❺	Switch between Symbol mode and ABC mode.
❻	Switch between Number mode and Edit mode.
❼	Clear your input.
❽	Start a new line.
❾	Minimise the virtual keypad.
❿	Enter text by voice. This feature may be unavailable depending on the selected input language.
⓫	Insert a space.

› Copy and paste text

While you are entering text, you can use the copy and paste feature to use text in other applications.

1. Touch and hold a word.
2. Drag or to select the text you want.
3. Select **Copy** to copy, or **Cut** to cut the text onto the clipboard.
4. In another application, touch and hold the text input field.
5. Select **Paste** to insert the text from the clipboard into the text input field.

Communication

Google Mail

You can retrieve new email messages from Google Mail™ to your Inbox. When you access this application, the Inbox screen appears. The total number of unread messages displays in the title bar and unread messages display in bold.

- This feature may be unavailable depending on your region or service provider.
- This Google Mail menu may be labelled differently depending on your region or service provider.

› Send an email message

1. Open the application list and select **Gmail**.
2. Select .
3. Enter a name or address in the recipient field.
4. Enter a subject and message.
5. Select → a file to attach an image file.
6. Select **Send** to send the message.

› View an email message

1. Open the application list and select **Gmail**.
2. Select an email message.

From the message view, use the following options:

- To move to the previous or next message, select **Older** or **Newer**.
- To search for an email message, select .
- To create a new message, select .

- To archive the message, select .
- To delete the message, select .
- To make the message as unread, select → **Mark unread**.
- To mark the message as important, select → **Mark as important**. The mark before the message title turns yellow.
- To add a label to a message, select → **Change labels**.
- To register the message to the spam list, select → **Report spam**.
- To hide the message, select → **Mute**. To move the message to the inbox folder, select **All Mail** and drag the message to **Inbox**.
- To reload the messages, select → **Refresh**.
- To customise the email settings, select → **Settings**.
- To reply to the message, select .
- To reply to the message including all recipients, select .
- To forward the message to other people, select .
- To add a star to the message, select ☆.
- To view an attachment, select **View**. To save it to your device, select **Save**.

Available options may vary depending on the account.

Email

Learn to send or view email messages via your personal or company email account.

› Set up an email account

1 Open the application list and select **Email**.

2 Enter your email address and password.

3 Select **Next** (for general email accounts) or **Manual setup** (for other company email accounts).

4 Follow the on-screen instructions.

5 To add more email accounts, select → **Settings** → **Add account** and repeat steps 2-4.

When you are finished setting up the email account, the email messages are downloaded to your device. If you have created more than two accounts, you can switch between email accounts; Select an account name at the top left of the screen and select the one you want to retrieve messages from.

› Send an email message

1 Open the application list and select **Email** → an email account.

2 Select .

3 Add recipients of your message.
- Enter email addresses manually, separating them with a semicolon.
- Select email addresses from the lists by selecting .

4 Select **+Cc/Bcc** and add more recipients.
You can also add yourself to the recipient list by selecting **+Me**.

5 Select the subject field and enter a subject.

6 Select the text input field and enter your email text.

7 Select → files to attach.

8 Select **Send** to send the message.

If you are offline or outside your service area, the message will be held in the outbox until you are online and in your service area.

› View an email message

When you open an email account, you can view previously retrieved emails offline or connect to the email server to view new messages. After retrieving email messages, you can view them offline.

1. Open the application list and select **Email** → an email account.
2. Select to update the message list.
3. Select an email message.

From the message view, use the following options:

- To move to the previous or next message, select ‹ or ›.
- To search for an email message, select .
- To reload the messages, select .
- To create a new message, select .
- To reply to the message, select .
- To forward the message to other people, select .
- To delete the message, select .
- To make the message as unread, select → **Mark as unread**.
- To move the message to another folder, select → **Move**.
- To view the messages by category, select → **List by**.
- To change the view mode, select → **View mode**.
- To change the background colour, select → **Background colour**.
- To print the message using a Wi-Fi or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.
- To create folders for managing your messages, select → **Create folder**.
- To customise the email settings, select → **Settings**.

- To add a star to the message, select ★.
- To save an attachment to your device, select the attachment tab → .

- Available options may vary depending on the account.
- Available options may differ in landscape view and portrait view.

Talk

Learn to chat with friends and family via Google Talk™.

This feature may be unavailable depending on your region or service provider.

› Set your status

1. Open the application list and select **Talk**.
2. Enter your Google account and password and select **Sign in** (if necessary).
3. Customise your status, image, and message to display.

› Add friends to your friend list

1. Open the application list and select **Talk**.
   The friend list shows all of your Google Talk contacts at a glance.
2. Select .
3. Enter an email address of the friend and select **Send invitation**.

When your friend accepts the invitation, the friend is added to your friend list.

› Start a chat

1. Open the application list and select **Talk**.
2. Select a friend from the friend list. The chat screen opens.
3. Enter your message and select ➤.
   To add a friend to a chat, select ◢ → **Add to chat**.
4. To end the chat, select ✕.

Social Hub

Learn to access Social Hub™, the integrated communication application for email, messages, contacts or calendar information. Visit socialhub.samsungapps.com for more details.

1. Open the application list and select **Social Hub**.
2. If you are launching this application for the first time, add an account or skip it for a later setup.
3. Select a category at the top left of the screen.
4. Check and use contents delivered from Social Hub.

Web

Browser

Learn to access and bookmark your favourite web pages.

- The web browser menu may be labelled differently depending on your region or service provider.
- Available icons may vary depending on your region or service provider.

› Browse web pages

1 Open the application list and select **Browser** to launch your homepage.
To access a specific web page, select the URL input field, enter the web address of the web page, and select .

2 Navigate web pages with the following keys:



The above screen may differ depending on your region or service provider.

Number	Function
1	Close the current tab.
2	Move backward or forward to web pages in history.

Number	Function
❸	Reload the current web page; While the device is loading web pages, this icon changes to ✕.
❹	Open a new tab.
❺	Search for information.
❻	Access a list of web browser options.
❼	Open a list of saved bookmarks and recent internet history.
❽	Bookmark the current web page.

While browsing the web page, use the following options:

- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen.

If you activated tilting motions, you can zoom in or out by touching and holding two points with your fingers and then tilting the device back and forth.

- To open a new tab, select → **New tab**.
- To open a new tab without saving cookies, select → **New incognito tab**.
- To search for text on the web page, select → **Find on page**.
- To send the web address of the web page to others, select → **Share page**.
- To save the current web page and read it offline later, select → **Save page**.

- To view page details, select → **Page info**.
- To view the items downloaded from the web, select → **Downloads**.
- To adjust the brightness of the screen, select → **Colour**.
- To print the web page using a Wi-Fi or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.
- To customise browser settings, select → **Settings**. ► p. 50

› Search for information by voice

This feature may be unavailable depending on your region or service provider.

1. Open the application list and select **Browser**.
2. Select .
3. Select and say a keyword into your device's microphone.
   The device searches for information and web pages related with the keyword.

› Open multiple pages

You can open multiple pages and switch back and forth between them.

1. Open the application list and select **Browser**.
2. Select to open a new tab.
3. Access another web page on the new tab.
4. To switch back and forth between currently open tabs, select the title of a tab.

› Bookmark your favourite web pages

If you know the web address of the web page, you can manually add a bookmark.

Add a bookmark

1. Open the application list and select **Browser**.
2. Select → .
   You can also select ★ to bookmark the current web page.
3. Enter a page title and a web address.
4. Select the **Bookmarks** drop-down menu and select a bookmark location to add (if necessary).
5. Select **OK**.

To use bookmark options, select , and touch and hold a bookmark:

- To open the web page in the current tab, select **Open**.
- To open the web page in a new tab, select **Open in new tab**.
- To edit the bookmark, select **Edit bookmark**.
- To add the bookmark shortcut to the Home screen, select **Add shortcut to home**.
- To send the web address of the web page to others, select **Share link**.
- To copy the web address of the web page, select **Copy link URL**.
- To delete the bookmark, select **Delete bookmark**.
- To use the web page as your homepage of the browser, select **Set as homepage**.

Create a bookmark folder

1. Open the application list and select **Browser**.
2. Select → → **New folder**.
3. Enter a name for the bookmark folder and select **Done**.

› Access recent history

1. Open the application list and select **Browser**.
2. Select → **History**.
3. Select a web page to access.

› Customise browser settings

1. Open the application list and select **Browser**.
2. Select → **Settings**.
3. Adjust the following settings to customise your web browser:

Option	Function
Set homepage	Enter the web address of a site to use as your homepage.
Sync with Google Chrome	Synchronise data or bookmarks saved on your device with your Google account.
Form auto-fill	Set to automatically fill in the personal information saved on your device.
Auto-fill data	Set which private information to save on your device.

Option	Function
Clear cache	Clear the temporary memory location of information from recently-accessed web pages.
Clear history	Delete your browsing history.
Show security warnings	Set to display a warning message when you access a dangerous website.
Accept cookies	Set to save and use cookies.
Clear all cookie data	Delete cookies saved in the device.
Remember form data	Set to remember your previous input and suggest it when entering text in a form.
Clear form data	Delete all saved form data.
Enable location	Set to use your location information.
Clear location access	Clear your location information saved on your device.
Remember passwords	Set to automatically save your web passwords.
Clear passwords	Delete all saved passwords.
Set search engine	Set an engine to use for web searches.
Open in background	Set to run the web browser in the background while using other applications.
Enable JavaScript	Set whether or not to run Java applets in web pages.

Option	Function
Enable plug-ins	Set when the device will enable plug-in.
Website settings	Customise settings for a website.
Open pages in overview	Set to display an overview of new web pages.
Auto-fit pages	Adjust web pages automatically to fit the screen.
Block pop-ups	Set whether or not to block pop-ups on web pages.
Load images	Set whether or not to load images on web pages.
Text encoding	Select a character encoding type.
Reset to default	Restore the web settings to the factory default.
Quick controls	Set to hide the address bar and use pop-up browser controls instead by touching the edge of the screen to access the Quick controls.
Most-visted homepage	Set to show frequently-visited pages.
Google Instant	Set to show search suggestions when you enter a keyword in the Google search bar.

Pulse

You can use the Pulse reader to add feeds for your favourite news topics and read news articles on your device.

› Read feeds

1. Open the application list and select **Pulse**.
2. If you are launching this application for the first time, select **OK** and touch the screen to clear the hint.
3. Select to update feeds.
   To read the feeds you added to your favourite list, select .me.
4. Scroll up or down to select a feed source.
5. Scroll left or right and select a feed.
6. While reading a feed, use the following options:
   - To add a feed to your favourite list, select .
   - To upload a feed to community websites, select f or .
   - To send a feed to others, select .
   - To return to a feed list, select .

› Manage feed sources

1. Open the application list and select **Pulse**.
2. Select to view the feed source list.
3. Select or to add or delete a feed source.

Market

Based on the Android platform, your device's functionality can be extended by installing additional applications. Android Market provides you an easy and quick way to shop for games and mobile applications.

This feature may be unavailable depending on your region or service provider.

› Download and install an application

1. Open the application list and select **Market**.
   You can also select **Shop** at the top right of the application list.
2. If you are launching this application for the first time, select **Accept**.
3. Search for a file or application and download it.

› Uninstall an application

1. Open the application list and select **Market**.
2. Select **My apps**.
3. Select the item you want to delete.
4. Select **Uninstall**.

YouTube

Learn to view and upload videos via YouTube™.

This feature may be unavailable depending on your region or service provider.

› Watch videos

1. Open the application list and select **YouTube**.
2. Select a video from the list.
3. Touch a video screen and select ⛶ to display a full screen.
4. Control playback with the virtual keys.

› Upload videos

1. Open the application list and select **YouTube**.
2. Select **Your Channel**.
3. Select your Google account if it is linked to YouTube. You can also select **Add account** and set up an account to sign in YouTube.
4. Select **Upload** and then select a video.
5. Enter details for the upload and select **Upload**.

Maps

Learn to use Google Maps™ to find your location, search the map for streets, cities, or countries, and get directions.

This feature may be unavailable depending on your region or service provider.

› Search for a specific location

1. Open the application list and select **Maps**.
2. If you are launching this application for the first time, select **OK**.
   The map will display your current location.
3. Select **Search Maps**.
4. Enter a keyword for the location and select .
   To search for a location by voice, select .
5. Select the location you want to view details.
   - To view your current location, select .
   - To switch to a compass view of the map that changes orientation when you move the device, select .

- To search for a place around you, select .
- To get directions to a specific destination, select .
- To add layers to the map, select .
- To access a list of other options, select .
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together.
- To add a star to the location, select .

› Get directions to a specific destination

1. Open the application list and select **Maps**.
2. Select .
3. Enter the addresses of the starting location and the ending location.

   To enter an address from your contact list or starred places, or point the location on the map, select → **Contacts**, **Point on map**, or **My Places**.
4. Select a travel method (car, bus, or walk) and select **Go**.

   The route is indicated on the map. Depending on the selected travel method, you may see multiple routes.
5. When you are finished, select → **Clear Map**.

Latitude

Learn to share your location with your friends and view friends' locations via Google Latitude™.

This feature may be unavailable depending on your region or service provider.

1 Open the application list and select **Latitude**.
The device automatically joins Latitude.

2 Select → **Select from Contacts** or **Add via email address**.

3 Select a friend you want to add, or enter an email address and select **Add friends**.

4 Select **Yes**.
When your friend accepts your invitation, you can share locations.

5 Select a friend from the list.
Your friends' locations are marked with their photos on the map.

Places

Learn to search for a place around you.

This feature may be unavailable depending on your region or service provider.

1 Open the application list and select **Places**.

2 Select a category.
Your device searches for places around your current location that are related to the category.

3 Select a place name to view its details.

4 While viewing information, use the following options:
- To view the place on the map, select **Map**.
- To view the route to the place, select **Directions**.
- To switch to a street-level view of the map, select **Street view**.

Navigation

Learn to use the GPS navigation system to find and show your destination with voice guidance.

- Navigation maps, your current location, and other navigational data may differ from actual location information. You should always pay attention to road conditions, traffic, and any other factors that may affect your driving and follow all safety warnings and regulations while driving.
- This feature may be unavailable depending on your region or service provider.

1. Open the application list and select **Navigation**.
2. If you are launching this application for the first time, select **Accept**.
3. Enter your destination by using one of the following methods:
   - **Speak Destination**: Speak your destination such as "Navigate to destination."
   - **Type Destination**: Enter your destination with the virtual keypad.
   - **Contacts**: Select your destination from addresses of your contacts.
   - **Starred Places**: Select your destination from the list of your starred places.
4. Follow the on-screen instructions to use the navigation service.

Readers Hub

Learn to use the integrated readers hub for accessing various reading materials.

Some features may be currently unavailable.

1. Open the application list and select **Readers Hub**.
2. If you are launching this application for the first time, read the disclaimer information and select **Confirm**.
3. Select an image of reading material.
4. Search for and download reading material from the online store.

Samsung Apps

Samsung Apps allows you to simply and easily download an abundance of applications directly to your device. Featuring a wealth of games, news, reference, social networking, navigation, health related applications and more, Samsung Apps gives you instant access to a huge choice of mobile experience.

Your device gets smarter with fully optimised applications from Samsung Apps. Explore amazing applications and make your mobile life even better.

- This feature may be unavailable depending on your region or service provider.
- For details, please visit www.samsungapps.com.

1. Open the application list and select **Samsung Apps**.
2. If you are launching this application for the first time, select a region → **OK**. Then read the terms and conditions and select **Accept**.
3. Search for and download applications as desired.

Entertainment

Music player

Learn to listen to your favourite music while on the go with the music player. The music player supports the following file formats: mp3, aac, ogg, wma, flac, m4a.

- You can also play music files in the following formats if you open them from My files or the web browser: mid, xmf, rtttl, imy, rtx, ota, amr, wav, mxmf.
- Some file formats are not supported depending on the software of the device.
- If the file size exceeds the available memory, an error can occur when you open files.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› Add music files to your device

Start by transferring files to your device or memory card:

- Download from the wireless web. ► p. 46
- Download from a PC with Samsung Kies. ► p. 85
- Receive via Bluetooth. ► p. 91
- Synchronise with Windows Media Player 11. ► p. 86
- Copy to your device. ► p. 86

› Play music

After transferring music files to your device or memory card,

1. Open the application list and select **Music player**.
2. Select a music category → a music file.
3. Touch the music player field.
4. Control playback with the virtual keys.

While playing music, use the following options:

- To add a music file to a playlist, select → **Add to playlist**.
- To listen to music via a Bluetooth headset, select → **Via Bluetooth**. You cannot use this option when you connect a headset to your device.
- To send a music file to others, select → **Share via**.
- To set a music file as an alarm tone, select → **Set as alarm tone**.
- To customise your music player, select → **Settings**.

- You can control the music player with a headset. In Idle mode, press and hold the headset button to launch the music player. Press the headset button to start or pause playback.
- You can experience virtual 5.1 surround sound when listening to multichannel content, such as DVD movies.

› Create a playlist

1. Open the application list and select **Music player** → **Playlists**.
2. Select → **New playlist**.
3. Enter a title for your new playlist and select **OK**.
4. To add music files to the playlist, select next to the music files you want to add and select **Done**.

› Customise music player settings

1 Open the application list and select **Music player**.

2 Select → **Settings**.

3 Adjust the following settings to customise your music player:

Option	Function
Equaliser	Select a default equaliser type.
Sound effects	Select a sound effect.
Lyrics	Set to display lyrics of songs during playback.
Music auto off	Set the music player to turn off automatically after a specific period of time.
Music menu	Select music categories to display on the music library screen.

Camera

Learn how to capture and view photos and videos. You can take photos at resolutions up to 2048 x 1536 pixels (3.2 megapixels) and videos at resolutions up to 1280 x 720 pixels.

- The camera automatically turns off when you do not use it for a specified period.
- The memory capacity may differ depending on the shooting scene or shooting conditions.

› Capture a photo

1 Open the application list and select **Camera** to turn on the camera.

2 Aim the lens at the subject and make any necessary adjustments.

Number	Function
1	Use camera shortcuts. • : Change the flash setting. • : Switch between the front and rear camera lense. • : Change the shooting mode. • : Select the length of the delay before the camera takes a photo. • : Adjust the exposure value. You can add or remove shortcuts to frequently used options. ► p. 72
2	Change the camera settings.
3	View the default storage location.
4	Switch to the camcorder.

Number	Function
5	Capture a photo.
6	Open the image viewer to view photos or videos you captured or recorded.

3 Touch where you want to focus on the preview screen.
The focus frame moves to the place you touch and changes to green when the subject is in focus.

4 Select to take a photo.
The photo is automatically saved in the /Root/DCIM/Camera folder as jpg files.

After taking photos, select the image viewer icon to view the captured photos.

- To view more photos, scroll left or right. You can also touch the screen and scroll through the thumbnails of photos at the bottom of the screen.
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen.
- To send a photo to others, select **Share via**.
- To set a photo as wallpaper or an image for a contact, select **Set as**.
- To delete a photo, select **Delete**.
- To access Gallery, select **Go to gallery**.

› Capture a photo by using preset options for various scenes

Your camera provides you with predefined settings for various scenes. You can simply select the proper mode for your shooting condition and subjects. For example, when you take photos at night, select the night mode that uses an extended exposure.

1 Open the application list and select **Camera** to turn on the camera.

2 Select → **Scene mode** → a scene.

3 Make any necessary adjustments.

4 Select to take a photo.

› Capture a photo in Self shot mode

You can take photos of yourself conveniently using the front camera lens.

1 Open the application list and select **Camera** to turn on the camera.

2 Select → **Self portrait**.

3 Make any necessary adjustments.

4 Select to take a photo.

› Capture a photo in Smile shot mode

Your camera can recognise people's faces and help you take photos of their smiling faces.

1 Open the application list and select **Camera** to turn on the camera.

2 Select → **Shooting mode** → **Smile shot**.

3 Make any necessary adjustments.

4 Aim the camera lens at your subject and select .
Your device recognises people in an image and detects their smiles. When the subject smiles, the device automatically takes a photo.

› Capture a panoramic photo

You can take wide panoramic photos using Panorama shooting mode. This mode is convenient for photographing landscapes.

1. Open the application list and select **Camera** to turn on the camera.
2. Select → **Shooting mode** → **Panorama**.
3. Make any necessary adjustments.
4. Select to take the first photo.
5. Slowly move the device in any direction and align the green frame with the viewfinder.
   When you have aligned the green frame and viewfinder, the camera will automatically take the next photo.
6. Repeat step 5 to complete the panoramic photo.

› Capture a photo of action

You can capture shots of a moving subject and then combine them into a single photo that shows the action.

1. Open the application list and select **Camera** to turn on the camera.
2. Select → **Shooting mode** → **Action shot**.
3. Make any necessary adjustments.
4. Select to take the first photo.
5. Move the device to follow the moving subject.
   The device automatically takes the next photos.
6. Continue to follow the subject until the device has captured all the shots necessary for the action photo.

› Customise camera settings

Before taking a photo, select ⚙ to access the following options:

Option	Function
Edit shortcuts	Edit shortcuts to frequently used options.
Self portrait	Switch between the front and rear camera lenses.
Flash	Change the flash setting; You can manually turn the flash on or off, or set the camera to automatically use the flash when needed.
Shooting mode	Change the shooting mode.
Scene mode	Change the scene mode.
Exposure value	Adjust the exposure value.
Focus mode	Take close-up photos or set the camera to focus on the subject.
Timer	Select the length of the delay before the camera takes a photo.
Effects	Apply a special effect, such as sepia or black and white tones.
Resolution	Change the resolution option.
White balance	Adjust the colour balance according to lighting conditions.
Metering	Select a type of exposure metre.

Option	Function
Outdoor visibility	Activate Outdoor visibility to select an appropriate lighting condition.
Guidelines	Display the guidelines on the preview screen.
GPS tag	Set the camera to include location information for your photos. • To improve GPS signals, avoid shooting in locations where the signal may be obstructed, such as between buildings or in low-lying areas, or in poor weather conditions. • Your location may appear on your photos when you upload them to the web. To avoid this, deactivate the GPS tag setting.
Storage	Select a memory location for storing captured photos.
Reset	Reset menus and shooting options.

› Record a video

1 Open the application list and select **Camera** to turn on the camera.

2 Drag the slider to switch to the camcorder.

3 Aim the lens at the subject and make any necessary adjustments.



Number	Function
1	Use camcorder shortcuts. • : Change the flash setting. • : Switch to the front camera lens and record a video of yourself. • : Change the recording mode (for attaching to a message or for saving normally). • : Select the length of the delay before the camera recording a video. • : Adjust the exposure value. You can add or remove shortcuts to frequently used options. ► p. 72
2	Change the camcorder settings.

Number	Function
❸	Check the camcorder status. • 02:29:16 : Length of video that can be recorded (according to available memory) • : Default storage location
❹	Switch to the camera.
❺	Record a video.
❻	Open the image viewer to view photos or videos you captured or recorded.

4 Touch where you want to focus on the preview screen.
The focus frame moves to the place you tap and changes to green when the subject is in focus.

5 Select to start recording.

6 Select to stop recording.
The video is automatically saved in the /Root/DCIM/Camera folder as mp4 files.

After recording videos, select the image viewer icon to view the recorded videos.

- To view more videos, scroll left or right. You can also touch the screen and scroll through the thumbnails of videos at the bottom of the screen.
- To play a video, select .
- To send a video to others, select **Share via**.
- To delete a video, select **Delete**.
- To access Gallery, select **Go to gallery**.

› Customise camcorder settings

Before recording a video, select ⚙ to access the following options:

Option	Function
Edit shortcuts	Edit shortcuts to frequently used options.
Self recording	Switch between the front and rear camera lenses.
Flash	Change the flash setting; You can manually turn the flash on or off.
Recording mode	Change the recording mode.
Exposure value	Adjust the exposure value.
Timer	Select the length of the delay before the camera starts recording a video.
Effects	Apply a special effect, such as sepia or black and white tones.
Resolution	Change the resolution option.
White balance	Adjust the colour balance according to lighting conditions.
Outdoor visibility	Activate Outdoor visibility to select an appropriate lighting condition.
Guidelines	Display the guidelines on the preview screen.
Storage	Select a memory location for storing recorded videos.
Reset	Reset menus and recording options.

› Edit the shortcut icons

You can add or remove shortcuts to frequently-used options.

1. From the preview screen, select → **Edit shortcuts**.
2. Tap and hold an icon from the option list and drag it to the shortcut area.

   To remove shortcuts, tap and hold an icon and drag it to the option list.
3. Tap the screen to return to the preview screen.

Video player

Learn to use the video player to play various kinds of videos. The video player supports the following file formats: 3gp (mp4), wmv (asf), avi, mkv, flv, webm.

- Avoid locking the device's screen while playing a DivX Video-On-Demand. Each time you lock the screen while playing a DivX Video-On-Demand, one of your available rental counts will be decremented.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

1. Open the application list and select **Video player**.
2. Select a view mode at the top of the screen.
3. Select a video to play.
4. Control playback with the virtual keys.

While playing a video, use the following options:

- To send a video to others, select → **Share via**.
- To trim a segment of a video, select → **Trim**.

- To view the list of bookmarks, select → **Bookmarks**. This option appears only if you have bookmarked during playback by selecting .
- To display subtitles, select → **Subtitles**. This option appears only when the subtitle file for the video is available.
- To apply a colour effect, select → **Colour tone**.
- To activate outdoor visibility to select an appropriate lighting condition, select → **Outdoor visibility**.
- To set the video player to play the next file automatically, select → **Auto play next**.
- To export the current video to Video maker, select → **Video maker**.
- To view video details, select → **Details**.

Gallery

Learn to view photos and play videos saved in your device's memory.

› Supported file formats

Type	Format
Photos	jpeg, png, gif, wbmp, bmp, agif
Videos	• Format: 3gp (mp4), wmv (asf), avi, mkv, flv, webm • Codec: mpeg4, H.264, H.263, DivX®, vc-1, wmv7/8, vp8 • Extension (File type): avi, divx, mpeg, mp4, m4v, 3gp, 3gpp, 3g2, 3gpp2, mkv, wmv, asf, flv

- Avoid locking the device's screen while playing a DivX Video-On-Demand. Each time you lock the screen while playing a DivX Video-On-Demand, one of your available rental counts will be decremented.
- Some file formats are not supported depending on the software of the device.
- If the file size exceeds the available memory, an error can occur when you open files.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› View a photo

1. Open the application list and select **Gallery**.
2. Select a folder.
3. Select a photo (with no icon) to view.

While viewing a photo, use the following options:

- To view more photos, scroll left or right.
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen.
- To start a slideshow of images, select . Touch the screen to stop the slideshow.
- To send a photo to others, select .
- To delete a photo, select .
- To view photo details, select → **Details**.
- To rotate a photo anti-clockwise, select → **Rotate left**.
- To rotate a photo clockwise, select → **Rotate right**.

- To set a photo as wallpaper or an image for a contact, select → **Set Picture As**.
- To crop an image from a photo, select → **Crop**.
- To print a photo using a Wi-Fi or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.
- To copy a photo, select → **Copy**.
- To use motion recognition, select → **Motion**.

› Play a video

1. Open the application list and select **Gallery**.
2. Select a folder.
3. Select a video (with the icon) to play.
4. Control playback with the virtual keys.

Photo editor

You can edit photos and apply various effects.

1. Open the application list and select **Photo editor**.
2. Select **Select picture** → a folder → an image.
   You can create a new photo by selecting **Capture picture**.
3. Select → **OK** and drag your finger over the area you want to select.
   - To change the type of the selection tool, select .
   - To add to or subtract from the selection border, select , , or . If you select **Grab**, you can adjust the selection size by selecting .
   - To reverse the selection, select .
4. Select **Done**.

5 Use the following options to edit the photo:

Option	Function
	Rotate or flip the image.
	Resize the image by dragging the rectangle or selecting **100%** → an option.
	Crop the image by moving or dragging the rectangle.
	Apply a colour effect.
	Apply a filter effect.
	Use additional tools, such as copying and warping.

- Select to undo your last action.
- Select to redo your last action.

6 Adjust the image as desired and select **Done**.

7 When you are finished, select .

8 Enter a name for the photo and select **OK**.

Video maker

You can edit videos and apply various effects. The video editor supports the following video resolutions and codecs:

Type	Format
Resolutions	320 x 240, 640 x 480, 720 x 480, 1280 x 720, 1920 x1080
Codecs	H.263, H.264, mpeg4

- Some video files in Gallery may not be viewable depending on the video resolutions and codecs.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› Create a video

1. Open the application list and select **Video maker**.
2. Rotate the device to landscape view.
3. Select **New project**.
4. Select a frame theme.
5. Select a media category.
6. Tap and hold a file, and then drag it to the bottom pane of the screen.
   - To select the duration that an image is shown, tap the image and select the duration icon.
   - To delete images or videos, tap and hold an item and then drag it to the trash bin.
   - To rearrange images or videos, tap and hold an item and drag it to a new location.
   - To crop images or videos, tap the image and select .
7. To add more files, repeat step 5-6.
8. Select **Transition** or and add a transition effect between images or videos.
9. Select **Effect** → an effect option.
10. When you are finished, select → **Export movie**.
11. Select a resolution and enter a name for the video → **OK**.

Game Hub

Learn to play social and premium games.

1. Open the application list and select **Game Hub**.
2. If you are launching this application for the first time, select **Confirm**.
3. Select and install a game.
4. Follow the on-screen instructions.

- Available games may vary depending on your region or service provider.
- Controls and options of games may vary.

Personal information

Contacts

Learn to create and manage a list of your personal or business contacts. You can save names, mobile phone numbers, home phone numbers, email addresses, birthdays and more for your contacts.

› Create a contact

1. Open the application list and select **Contacts**.
2. Select +.
3. Select a memory location.
   If you have more than one account, select an account to which you want to add the contact.
4. Enter contact information.
5. Select **Done** to add the contact to memory.

› Retrieve contacts by your account

You can retrieve contacts by synchronising your assigned account.

1. Open the application list and select **Contacts**.
2. Select → **View SNS friends**.
3. Select an account.
4. Select contacts → **Done**.
   An updated contact list is retrieved and saved on your device automatically.

› Find a contact

1. Open the application list and select **Contacts**.
2. Select **Search contacts** and enter the first few letter of a name.
3. Select the contact's name.

Once you find a contact, you can use the following options:

- To send an email message, select .
- To edit the contact information, select .
- To delete the contact, select → **OK**.
- To set the contact as your favourite, select ★.

› Import or export contacts

To import contact files (in vcf format) from your device's USB storage,

1. Open the application list and select **Contacts**.
2. Select → **Import/Export** → **Import from SD card**.
3. Select a memory location.
   If you have more than one account, select an account to which you want to add the contact.
4. Select an option for importing a single contact file, multiple contact files, or all contact files, and select **OK**.
5. Select contact files to import and select **OK**.

To export contacts to your device's USB storage,

1. Open the application list and select **Contacts**.
2. Select → **Import/Export** → **Export to SD card**.
3. Select **OK** to confirm.

› Create your namecard

1. Open the application list and select **Contacts**.
2. Select → **My profile**.
3. Select **Edit**.
4. Enter your own personal details.
5. Select **Done**.

You can send your namecard by attaching it to a message or an email or transferring it via the Bluetooth wireless feature.

› Create a group of contacts

1. Open the application list and select **Contacts**.
2. Select **Groups** → .
3. Enter a name for the group.
4. Select **Edit members**.
5. Select members from the contact list and select **Done**.
6. When you are finished, select **Done**.

Calendar

Learn to create and manage daily, weekly, or monthly events, and set alarms to remind yourself of important events.

› Change the calendar view

1. Open the application list and select **Calendar**.
2. Select a view mode from the top of the calendar.
   - **Day**: Hourly blocks for one full day
   - **Week**: A list of scheduled appointments for the days in one full week
   - **Month**: Daily blocks for the current month
   - **List**: A list of all scheduled appointments

› Create an event

1. Open the application list and select **Calendar**.
2. Select +.
3. If an alert message about the calendar sync appears, select **Done**.
4. Enter the details of the event as required.
5. Select **Done**.

› View events

To view today's schedule,

1. Open the application list and select **Calendar**.
2. Select **Today**.
3. Select an event to view its details.

To view events of a specific date,

1. Open the application list and select **Calendar**.
2. Select a date on the calendar.
   To move to a specific day by entering a date manually, select → **Go to**, enter the date by selecting ▲ or ▼, and select **Set**.
3. Select an event to view its details.

› Stop an event alarm

If you set an alarm for a calendar event, the event alarm icon will appear at the specified time.

1. Select on the system bar.
2. Select a reminder to view more details about the event.
3. To snooze or dismiss the reminder, select the check box next to events you want and select **Snooze** or **Dismiss**.

Memo

Learn to record important information to save and view at a later date.

› Create a memo

1 Open the application list and select **Memo**.
2 Select .
3 Enter your memo text.
4 Select **Done**.

› View memos

1 Open the application list and select **Memo**.
2 Select a memo to view its details.
To use additional features with a memo, select .

Tool	Function
	Delete the memo.
	Change the background colour of the memo.
	Lock the memo.
	Print the memo using a Wi-Fi or USB connection. Your device is compatible only with some Samsung printers.
	Upload your memo on community websites.
	Send the memo to others.

Connectivity

PC connections

Learn to connect your device to a PC with a USB cable in various USB connection modes. By connecting the device to a PC, you can synchronise files with Windows Media Player, transfer data to and from your device directly, and use the Samsung Kies program.

To use PC connections, you must deactivate USB debugging mode. Open the application list and select **Settings** → **Applications** → **Development**, and then clear the check box next to **USB debugging**.

› Connect with Samsung Kies

Ensure that Samsung Kies is installed on your PC. You can download the program from the Samsung website (www.samsung.com/kies).

1. Using a USB cable, connect the multifunction jack on your device to a PC. Samsung Kies will launch automatically.
   If Samsung Kies does not launch automatically, double-click the Samsung Kies icon on your PC.
2. Copy files from the PC to the device.
   Refer to the Samsung Kies help for more information.

› Synchronise with Windows Media Player

Ensure that Windows Media Player is installed on your PC.

1. Using the USB cable, connect the multifunction jack on your device to a PC with Windows Media Player installed. When connected, a pop-up window will appear on the PC.
2. Open Windows Media Player to synchronise music files.
3. Edit or enter your device's name in the pop-up window (if necessary).
4. Select and drag the music files you want to the sync list.
5. Start synchronisation.

› Connect as a mass storage device

You can connect your device to a PC as a removable disk and access the file directory. If you insert a memory card in the device, you can access the file directory of the memory card by using the device as a memory card reader.

1. Using the USB cable, connect the multifunction jack on your device to a PC.
2. Open the folder to view files.
3. Copy files from the PC to your device.

To disconnect the device from the PC, click the USB device icon on the Windows task bar and click the option to safely remove the mass storage device. Then remove the USB cable from the PC. Otherwise, you may lose data stored on your device or damage your device.

Wi-Fi

Learn to use your device's wireless networking capabilities to activate and connect to any wireless local area network (WLAN) compatible with the IEEE 802.11 a/b/g/n standards.

You can connect to the internet or other network devices anywhere an access point or wireless hotspot is available.

Your device uses non-harmonised frequency and is intended for use in all European countries. The WLAN can be operated in the EU without restriction indoors, but cannot be operated outdoors in France.

› Activate the Wi-Fi feature

1 Open the application list and select **Settings** → **Wireless and networks**.

2 Select **Wi-Fi** to activate the Wi-Fi feature.

An active Wi-Fi running in the background will consume battery power. To preserve battery power, activate the Wi-Fi feature only when needed.

› Find and connect to a Wi-Fi AP

1 Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings**.

The device will automatically search for available Wi-Fi APs.

2 Select a network under **Wi-Fi networks**.

3 Enter a password for the network (if necessary).

4 Select **OK**.

› Add a Wi-Fi AP manually

1. Open the application list and select **Settings** → **Wireless and networks** → **Wi-Fi settings** → **Add Wi-Fi network**.
2. Enter the SSID for the network and select the security type.
3. Set the security settings depending on the selected security type.
4. Select **Save**.

Wi-Fi Direct

Learn to use the Wi-Fi Direct feature to connect two devices via a Wi-Fi network without requiring an access point.

› Connect your device to another device

1. Open the application list and select **Settings** → **Wireless and network** → **Wi-Fi Direct settings** → **OK** → **Wi-Fi Direct**.
2. Select → **Scan**.
3. Select a device and then select **Connect**.
   When the owner of the other device accepts the connection, the devices are connected.

› Send data via Wi-Fi

1 Select a file or item, such as a memo, media file, or web address, from an appropriate application or My files.

2 Select an option for sending data via Wi-Fi.

The method for selecting an option may vary by data type.

3 Search for and select another device.

› Receive data via Wi-Fi

When prompted, select **OK** to confirm that you are willing to receive data. Received data is saved to the ShareViaWifi folder.

Bluetooth

Bluetooth is a short-range wireless communications technology capable of exchanging information over a distance of about 10 m without requiring a physical connection.

You do not need to line up the devices to beam information with Bluetooth. If the devices are within range of one another, you can exchange information between them even if they are located in different rooms.

- Samsung is not responsible for the loss, interception, or misuse of data sent or received via the Bluetooth wireless feature.
- Always ensure that you share and receive data with devices that are trusted and properly secured. If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your device.

› Turn on the Bluetooth wireless feature

1 Open the application list and select **Settings** → **Wireless and networks**.

2 Select **Bluetooth** to turn on the Bluetooth wireless feature.

› Find and pair with other Bluetooth-enabled devices

1 Open the application list and select **Settings** → **Wireless and networks** → **Bluetooth settings** → **Scan for nearby devices**.

2 Select a device.

3 Enter a PIN for the Bluetooth wireless feature or the other device's Bluetooth PIN, if it has one, and select **OK**. Alternatively, select **Accept** to match the PIN between your device and the device.

When the owner of the other device enters the same PIN or accepts the connection, pairing is complete. If the pairing is successful, the device will automatically search for available services.

Some devices, especially headsets or hands-free car kits, may have a fixed Bluetooth PIN, such as 0000. If the other device has a PIN, you must enter it.

› Send data using the Bluetooth wireless feature

1. Select a file or item, such as a contact, calendar event, memo, or media file, from an appropriate application.
2. Select an option for sending data via Bluetooth.

The method for selecting an option may vary by data type.

3. Search for and pair with a Bluetooth-enabled device.

› Receive data using the Bluetooth wireless feature

1. Open the application list and select **Settings** → **Wireless and networks** → **Bluetooth settings** → **Visible**.
2. When prompted, enter the PIN for the Bluetooth wireless feature and select **OK** (if necessary).
3. Select on the system bar and select **Accept** to confirm that you are willing to receive data from the device.

Received data is saved to the bluetooth folder. If you receive a contact file, select **My files** → **bluetooth** → a contact file to import it to your contact list.

AllShare

Learn to use the Digital Living Network Alliance (DLNA) service that enables you to share media files between DLNA-enabled devices in your home over a Wi-Fi feature.

You must first activate the Wi-Fi feature and add a Wi-Fi profile. ► p. 87

- The supported file formats may vary depending on the software of the device.
- Some files may not play on the DLNA- enabled devices depending on the devices.

› Customise DLNA settings for sharing media files

To allow other DLNA-enabled devices to access media files on your device, you must activate media sharing.

1. Open the application list and select **AllShare**.
2. Select .
3. Adjust the following settings to customise the DLNA feature:

Option	Function
Media server name	Enter a name for your device as a media server.
Share media	Turn on video, image, and music sharing with other DLNA-enabled devices.
Access point network	Select a connection profile to use for DLNA connections.
Upload from other devices	Set whether or not to accept the upload from other devices.
Default memory	Select the default memory location for saving downloaded media files.

› Play your files on another DLNA-enabled device

1. Open the application list and select **AllShare**.
2. Select **My device**.
3. Select a media category → a file.
4. Select a player—the one that will play the media file. Playback begins at the selected player.
5. Control playback using icons of your device.

Playback may be buffered, depending on the network connection and the connected server.

› Play others' files on your device

1. Open the application list and select **AllShare**.
2. Select a device as the media server—the one that contains media files.
3. Select a media category → a file.
   Playback begins at the selected player.
4. Control playback using icons of your device.

› Play files of one device on the other device

1. Open the application list and select **AllShare**.
2. Select a device as the media server—the one that contains media files.
3. Select a media category → a file.
4. Select .
   Your device automatically searches for DLNA-enabled devices.
5. Select a player—the one that will play the media file.
   Playback begins at the selected player.
6. Control playback using icons of your device.

GPS

Your device is equipped with a global positioning system (GPS) receiver. Learn to activate location services.

To receive better GPS signals, avoid using your device in the following conditions:

- between buildings, in tunnels or underground passages, or inside buildings

- in poor weather
- around high voltage or electromagnetic fields
- in a vehicle with sun protection film

Do not touch or cover the antenna area with your hands or other objects while using the GPS functions.

This feature may be unavailable depending on your region or service provider.

› Activate location services

You must activate location services to receive location information and search the map.

1 Open the application list and select **Settings** → **Location and security**.

2 Adjust the following settings to activate location services:

Option	Function
Use wireless networks	Set to use Wi-Fi and/or mobile networks for finding your location.
Use GPS satellites	Set to use the GPS satellite for finding your location.
Use location for Google Search	Set the device to use your current location for Google search and other Google services.

VPN connections

You can create virtual private networks (VPN) and connect to your private network securely through a public network, such as the internet.

Before you add a VPN, you must determine which VPN protocol to use. The following protocols are available: PPTP (Point-to-Point Tunneling Protocol), L2TP (Layer 2 Tunneling Protocol), L2TP/IPSec PSK (Pre-shared key based L2TP/IPSec), and L2TP/IPSec CRT (Certificate based L2TP/IPSec)

Your device should already be configured with internet access. If you have trouble accessing the internet, you need to edit connections. If you are not sure about the connection information to enter, ask your service provider.

› Set up VPN connections

1. Open the application list and select **Settings** → **Wireless and networks** → **VPN settings** → **Add VPN**.
2. Select a VPN type.
3. Customise the connection information.

Available options may vary depending on the VPN type.

Option	Function
VPN name	Enter a name of the VPN server.
Set VPN server	Enter the IP address of the VPN server.
Enable Encryption	Set to encrypt the VPN server.
Set IPSec pre-shared key	Enter a pre-shared key.
Enable L2TP secret	Set to use the L2TP secret password.

Option	Function
Set L2TP security	Enter the L2TP secret password.
Set user certificate	Select a user certificate that the VPN server uses to identify you. You can import certificates from the VPN server or download from the web.
Set CA certificate	Select a certificate authority (CA) certificate that the VPN server uses to identify you. You can import certificates from the VPN server or download from the web.
DNS search domains	Enter the domain name server (DNS) address.

4 When you are finished, select → **Save**.

› Connect to a private network

1 Open the application list and select **Settings** → **Wireless and networks** → **VPN settings**.

2 Select a private network to connect.

3 Enter the user name and password and select **Connect**.

Tools

Alarm

Learn to set and control alarms for important events.

› Set a new alarm

1. Open the application list and select **Alarm**.
2. Select .
3. Set alarm details.
4. When you are finished, select **Done**.

› Stop an alarm

When the alarm sounds,

- To stop the alarm, drag in any direction until it reaches the border of the circle.
- To repeat the alarm after a specified length of time, drag in any direction until it reaches the border of the circle.

› Delete an alarm

1. Open the application list and select **Alarm**.
2. Select an alarm to delete.
3. Select **Delete** → **OK**.

You can delete or deactivate alarms by touching and holding an alarm and selecting **Delete alarm** or **Deactivate alarm**.

Calculator

Learn to perform mathematical calculations directly on your device like a typical hand-held or desktop calculator.

1. Open the application list and select **Calculator**.
2. Use the keys that correspond to the calculator display to perform a basic or scientific calculator.

Downloads

Learn to manage logs of files you have downloaded from the web and email.

1. Open the application list and select **Downloads**.
2. Select a downloaded file.
3. To open a downloaded file, select the log.
   To delete a file, select the check box and then select .

eBook

Learn to open and read books and PDF files.

› Read books

1. Open the application list and select **eBook**.
2. If you are launching this application for the first time, read the disclaimer and select **Confirm**.
3. Select a book from the bookshelf.
4. To move pages, drag your finger left or right or touch near the left or right margin of a page.

5 Touch the screen and use the following options:

- To view the table of contents, bookmarks, or highlights, select .
- To adjust the brightness of the display, select .
- To customise the settings for fonts and theme, select .
- To read a book via the text-to-speech feature, select → **Read**.
- To search for text in the book, select .
- To bookmark the current page, select .
- To copy a word, touch and hold a word and select **Copy** from the pop-up window.
- To highlight a word, tap and hold a word and select **Highlight** from the pop-up window.
- To add a memo, touch and hold a word and select **Memo** from the pop-up window.
- To look up a word via the web, touch and hold a word and select **Search** from the pop-up window.

6 Create a drawing memo with the following tools:

Tool	Function
	Highlight the text.
	Write or draw on the book.
	Erase the drawing.
	Customise the pen and highlight settings.

› Import book files

You can import book files (in epub format) from the internal memory.

- DRM-protected book files are not supported.
- You can purchase a book via online bookstore by selecting .

1 Open the application list and select **eBook**.
2 Select → **Import**.
3 Select book files to import and select **Done**.

Google Search

You can search for applications and data in your device and specific data on the web.

1 Open the application list and select **Google Search**.
2 Enter a letter or a word of the data to search for.
Search for information by voice, select .
3 Select the item's name you want to access.

My files

Learn to quickly and easily access all of your photos, videos, music, sound clips, and other types of files stored on your device.

› Supported file formats

Type	Format
Photos	jpeg, png, gif, wbmp, bmp, agif
Videos	• Format: 3gp (mp4), wmv (asf), avi, mkv, flv, webm • Codec: mpeg4, H.264, H.263, DivX®, vc-1, wmv7/8, VP8 • Extension (File type): avi, divx, mpeg, mp4, m4v, 3gp, 3gpp, 3g2, 3gpp2, mkv, wmv, asf, flv

Type	Format
Audio	• Codec: mp3, vorbis, wma, aac, aac+, eaac+, amr (nb, wb), midi, wav, ac-3 (video play only), flac • Extension (File type): mp3, mp4, mpga, m4a, 3ga, 3gp, 3gpp, 3g2, 3gpp2, asf, wav, amr, awb, wma, ogg, oga, aac, mka, mid, midi, xmf, mxmf, ota, rtttl, smf, imy, rtx, ota, flac

- Some file formats are not supported depending on the software of the device.
- If the file size exceeds the available memory, an error can occur when you open files.
- Playback quality may vary by content type.
- Some files may not play properly depending on how they are encoded.

› Open a file

1. Open the application list and select **My files**.
2. Select a drop-down menu and select an option to sort the file list.
3. Select a folder.
   - To move up one level in the file directory, select .
   - To return to the top level of the file directory, select .
4. Select a file to open.

› Create a folder

1. Open the application list and select **My files**.
2. Select .
3. Enter a name and select **Done**.

› Copy or move files

1. Open the application list and select **My files**.
2. Select a check box next to folders or files to copy or cut.
3. Select or .
4. Locate a folder and select .

› Send files

1. Open the application list and select **My files**.
2. Select a check box next to files to send.
3. Select → an option.

› Delete files

1. Open the application list and select **My files**.
2. Select a check box next to folders or files to delete.
3. Select → **Yes**.

Pen memo

Learn to create sketch memos with various tools.

1. Open the application list and select **Pen memo**.
2. Select .
3. Create a drawing memo with the following tools:

Tool	Function
	Enter your text.
	Write or draw on the screen.
	Erase the sketch.
	Customise the tool settings.

You can also use the following options:

- To insert a photo, memo, or map, select → **Insert**.
- Select to undo your last action.
- Select to redo your last action.

4 When you are finished, select **Done**.

Polaris Office

Learn to create or view Microsoft Word, Excel, PowerPoint, and Adobe PDF files on your device. This application supports the following file formats: doc, docx, xls, xlsx, csv3, ppt, pptx, pps4, txt, hwp, rtf.

› Create a new document

1 Open the application list and select **Polaris Office**.

2 If you are launching this application for the first time, register as a online user or skip the registration.

3 Select **New file** → a document type.

4 Enter contents in the document.

5 When you are finished, select .

6 Enter a name for the document and select the location to save the document.

7 Select **Save**.

› Open a document

1 Open the application list and select **Polaris Office**.

2 Select **Local Storage** → a document file.

To open the recent file you have opened, select a file under **Recent Files**.

3 View the document as desired.

- To open the toolbar to edit the document (word, presentation, or excel file), select .
- To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also select → an option.
- To search for text on the document, select → **Find**.
- To bookmark the current page, select → **Bookclip**.
- To adjust the document to fit the screen, select → **Reflow text**.
- To send a file to others, select → **Send**.
- To read the document via the text-to-speech feature, select → **Text to speech**.
- To print the file using a Wi-Fi or USB connection, select → **Print**. Your device is compatible only with some Samsung printers.

Available options may vary depending on a document type, or in landscape view and portrait view.

› Manage documents online

1 Open the application list and select **Polaris Office**.

2 Select **Add Account**.

3 Enter your email address and password to access your account, and then select **OK**.

4 View and manage your documents on the server as desired.

Task Manager

With the task manager, you can view currently running applications and memory information.

1 Open the application list and select **Task Manager**.

2 Use the following options:

- **Activity applications**: View the list of all the applications currently running on your device.
- **Download**: View the total amount of memory used for applications installed on your device.
- **RAM manager**: Check and manage the RAM memory.
- **Storage**: View the used and available memory on your device and memory card.
- **Help**: View help information about extending battery life.

Voice Search

Learn to use the voice command feature to send a message or search for locations and information by voice.

This feature may be unavailable depending on your region or service provider.

1 Open the application list and select **Voice Search**.

2 Select **Speak now** (if necessary).

3 Say a command into the microphone.

4 Select the item's name you want to access.

World clock

Learn to view the time in another region.

1. Open the application list and select **World clock**.
2. Select +.
3. Enter a city name and select a city from the list.
   You can select a city in the world map view.
4. Select +.
5. To add more world clocks, repeat steps 2-4.

To apply the summer time to the clocks, touch and hold a clock and select **DST settings**.

Settings

Access the Settings menu

1 Open the application list and select **Settings**.

2 Select a setting category and select an option.

Wireless and networks

Change the settings for wireless network connections.

› Flight mode

Flight mode is useful when you are in an aeroplane, or in a place where accessing network data is prohibited. When you switch to Flight mode, all wireless functions on your device are disabled. You can use only non-network features, such as the camera, music player, ebook reader, or document viewer.

› Wi-Fi

Turn the Wi-Fi feature on or off.

› Wi-Fi settings

- **Wi-Fi**: Turn the Wi-Fi feature on or off. ► p. 87
- **Network notification**: Set the device to notify you when an open network is available.
- **Wi-Fi sleep policy**: Set when the device will turn off the Wi-Fi feature.
- **Add Wi-Fi network**: Add Wi-Fi APs manually.

› Wi-Fi Direct settings

- **Wi-Fi Direct**: Activate the Wi-Fi Direct feature to connect two devices via Wi-Fi without requiring an access point. ► p. 88
- **Device name**: View or edit your device's name.
- **Status**: View the connection status.
- **Disconnect Wi-Fi Direct**: Deactivate the Wi-Fi Direct feature.

› Kies via Wi-Fi

Connect your device to Samsung Kies via Wi-Fi.

› Bluetooth

Turn the Bluetooth wireless feature on or off.

› Bluetooth settings

- **Bluetooth**: Turn the Bluetooth wireless feature on or off. ► p. 90
- **Device name**: Set a Bluetooth name for your device.
- **Visible**: Set your device to be visible to other Bluetooth devices.
- **Visible time-out**: Set duration that your device is visible.
- **Show received files**: View files received from other devices via the Bluetooth wireless feature.
- **Scan for nearby devices**: Search for available Bluetooth devices.

› VPN settings

Set up and connect to virtual private networks (VPNs). ► p. 95

Sound

Change the settings for various sounds on your device.

- **Vibrate**: Set when the device will vibrate for various events.
- **Volume**: Adjust the volume level for notifications, media sounds, alarm ringtones, and system sounds.
- **Vibration intensity**: Adjust the vibration intensity of the haptic feedback.
- **Notification ringtone**: Select a ringtone to alert you to events.
- **Audible selection**: Set the device to sound when you select an application or option on the touch screen.
- **Screen lock sounds**: Set the device to sound when you lock or unlock the touch screen.
- **Haptic feedback**: Set the device to vibrate when you touch the keys.

Screen

Change the settings for the display.

- **Brightness**: Activate the automatic brightness or set the brightness of the display.
- **Screen display**:
  - **Font style**: Change the font type for the display text. You can download fonts from Android Market by selecting **Get fonts online**.
  - **Home screen**:
    Wallpaper: Select a background image for the Home screen.

- **Lock screen**:
  Wallpaper: Select an image to display when the screen is locked.

- **Mode**: Select a display mode.
- **Auto-rotate screen**: Set whether or not to rotate the content automatically when the device is rotated.
- **Animation**: Set the device to display animation when you switch between windows.
- **Timeout**: Set the length of time the device waits before turning off the display's backlight.
- **Quick launch**: Select an application to create a shortcut. You can launch the application by selecting .
- **Auto adjust screen power**: Set to save power by adjusting the brightness of the display.
- **Horizontal calibration**: Calibrate the accelerometer to adjust the horizontal axis of the device for better motion recognition.

Power saving mode

- **Use Custom power saving**: Automatically activate Power saving mode when the battery is low.
- **Custom power saving settings**:
  - **Power saving mode on**: Select a power level for Power saving mode.
  - **Turn off Wi-Fi**: Deactivate the Wi-Fi feature when the device is not connected with a Wi-Fi AP.

- **Turn off Bluetooth**: Deactivate the Bluetooth feature when not in use.
- **Turn off GPS**: Deactivate the GPS feature when not in use.
- **Turn off Sync**: Turn off sync when the device is not synchronising with a web server.
- **Brightness**: Activate the brightness setting for Power saving mode.
- **Brightness**: Set the brightness level for Power saving mode.
- **Timeout**: Set the length of time the device waits before turning off the display's backlight.

• **Learn about power saving**: Learn how to reduce battery consumption.

Location and security

Change the settings for securing your device and GPS functionality.

• **Use wireless networks**: Set to use Wi-Fi and/or mobile networks for finding your location.

• **Use GPS satellites**: Set to use the GPS satellite for finding your location.

• **Use location for Google Search**: Set the device to use your current location for Google search and other Google services.

• **Configure lock screen**: Set how to unlock the screen.
- **Off**: Disable the screen lock.
- **Unsecure**: Set to use the screen lock without a PIN, password, or pattern.
- **Pattern**: Set an unlock pattern to unlock the screen.
- **PIN**: Set a PIN (numeric) to unlock the screen.
- **Password**: Set a password (alphanumeric) to unlock the screen.

- **Owner information**: Edit the text you want to display on the screen in Screen lock mode.
- **Encrypt device**: Set a PIN or a password to encrypt the device to protect data and information saved on the device. Once the device is encrypted, you must enter the password each time you turn on the device. You must first charge the battery because it may take more than an hour to encrypt your device.
- **Encrypt SD card**:
  - **Encrypt SD card**: Protect your personal information by encrypting the data on your memory card.
  - **Full encryption**: Set to encrypt all files on your memory card.
  - **Exclude multimedia files**: Set to encrypt all files except multimedia files on your memory card.

You may not access the encrypted memory card after the factory data reset. First, decode the memory card before the factory data reset.

- **Remote controls**: Set to control a lost device remotely via the web.
- **Visible passwords**: Set the device to display your password as you enter.
- **Device administrators**: View device administrators installed on your device. You can activate device administrators to apply new policies to your device.
- **Use secure credentials**: Use certificates and credentials to ensure secure use of various applications.
- **Install from USB storage**: Install encrypted certificates that are stored in the USB storage.
- **Set password**: Create and confirm a password for accessing credentials.
- **Clear storage**: Erase the credential contents from the device and reset the password.

Applications

Change the settings for managing installed applications.

- **Manage applications**: Access the list of the applications installed on the device and check the application information.
- **Running services**: View the services you are using and access them to manage.
- **Memory usage**: View available memory and the memory used by applications.
- **Battery use**: View the amount of power consumed by your device.
- **Unknown sources**: Select to download applications from any source. If you do not select this option, you can download applications only from Android Market.
- **Development**:
  - **USB debugging**: Select to connect your device to a PC by using a USB cable. This is for application development.
  - **Stay awake**: Set the device's screen to stay on while charging the battery.
  - **Allow mock locations**: Allow mock locations and service information to be sent to a Location Manager service for testing. This is for application development.
- **Samsung Apps**: Select a network connection (Wi-Fi or packet switched data network) to get notifications for new applications from Samsung Apps.

This feature may be unavailable depending on your region or service provider.

Accounts and sync

Change the settings for the auto sync feature or manage accounts for synchronisation.

- **Background data**: Select this setting to use the auto sync feature. The auto sync will run in the background without opening applications and synchronise data.
- **Auto-sync**: Set the device to synchronise contact, calendar, and email data automatically.

Motion

Change the settings that control motion recognition on your device.

- **Motion activation**: Set to use motion recognition.
- **Tilt to zoom**: Set to zoom in or out while viewing images in Gallery or browsing web pages when you touch and hold two points with your fingers and then tilt the device back and forth.
- **Pan to edit**: Set to move an item to another page when you touch and hold the item and then pan the device to the left or right.

Privacy

Manage your device's use of personal information.

- **Back up my data**: Enable or disable to back up of your information to the Google server.
- **Backup account**: Add and view your Google account to back up your data. This option is available only when you activate **Back up my data**.
- **Automatic restore**: When enabled, backup settings are restored when you reinstall an application.

- **Factory data reset**: Use Factory data reset to return your device to its factory defaults. This setting erases all data from the device, including Google or other email account settings, system and application data and settings, and downloaded applications, as well as your music, photos, videos, and other files. If you reset the device in this way, the next time you turn on your tablet you are prompted to reenter the same kind of information as when you first started Android.

Storage

View memory information for your device and memory card. You can also format the memory card.

Formatting a memory card will permanently delete all data from the memory card.

Language and input

Change the settings for text input, the voice recogniser, and the text-to-speech feature.

› Select language

Select a display language for all menus and applications.

› Voice recognition settings

- **Language**: Select a language for the Google voice recognition.
- **SafeSearch**: Set the device to filter explicit text and/or images from voice search results.
- **Block offensive words**: Hide offensive words your device recognised from voice search results.

› Text-to-speech settings

- **Listen to example**: Play a sample of speech synthesis (available only when voice data is installed).
- **Always use my settings**: Set to use the speech rate and language settings you specify over the settings saved in applications.
- **Default engine**: Choose the default text-to-speech engine application.
- **Install voice data**: Download and install the speech synthesis data needed to activate Text-to-speech from Android Market.
- **Speech rate**: Set the speed at which the text is spoken.
- **Language**: Set the language for spoken text.
- **Engines**: Configure settings for installed voice recognition engines.

› Current input method

View a default keyboard type for text input.

› Input method selector

Set the device to hide or display the text input settings icon (⌨). If you select **Automatic**, your device will automatically hide or display the icon, based on the keyboard.

› Configure input methods

- **Swype**
  - **Swype**: Set the device to use the Swype keyboard.
  - **Settings**:
    Select Input Method: Select a keyboard type for text input.
    How to Swype: Learn how to enter text with the Swype keyboard.

Personal dictionary: Set up your own dictionary. The words in your dictionary will appear as suggestions for your text inputs.

Preferences:

- **Audio feedback**: Set to alert you when there are no alternative words for your input if you double-tap a word.
- **Vibrate on keypress**: Set the device to vibrate when you touch a key.
- **Show tips**: Set the device to automatically display tips for your actions when available.
- **Auto-spacing**: Set the device to automatically insert a space between words.
- **Auto-capitalization**: Set the device to automatically capitalise the first letter after a final punctuation mark, such as a full stop, question mark, or exclamation mark.
- **Show complete trace**: Set to display the trace of your dragging on the keyboard.
- **Word suggestion**: Set the device to display suggestions while you are entering text.
- **Speed vs. accuracy**: Set the balance for the speed and accuracy.
- **Reset Swype's dictionary**: Delete the words you have added to the dictionary.
- **Version**: View version information.

Language Options: Select languages for text input.

- **Android keyboard**
  - **Android keyboard**: Set the device to use the Android keyboard.
  - **Active input methods**: Select languages for text input.
  - **Settings**:

    Auto-capitalisation: Set the device to automatically capitalise the first letter after a final punctuation mark, such as a full stop, question mark, or exclamation mark.

Vibrate on key-press: Set the device to vibrate when you touch a key.

Sound on key-press: Set the device to sound when you touch a key.

Auto-correction: Set the device to automatically correct the misspelled words.

Show correction suggestions: Set the device to predict words according to your input and display word suggestions.

- **DioPen Chinese IME**
  - **DioPen Chinese IME**: Set the device to use the DioPen Chinese keyboard.
  - **Settings**:

    Keypad types: Select the default input method, such as the QWERTY keyboard or handwriting screen.

    Language Settings: Select languages for text input.

    Show suggestions: Set the device to display word suggestions for your input.

    Detail settings: Customise the settings for DioPen Chinese IME keypad, such as word suggestion, spell check, and auto space when **Show suggestions** is selected.

    Recognize delay time: Set how fast your device will recognize your handwriting to convert it to characters.

    Pen thickness: Select a line thickness for Handwriting mode.

    Pen color: Select a line colour for Handwriting mode.

    Use Fuzzy: Activate the Fuzzy input feature so that you can easily enter Chinese characters that are similar in phonetic spelling.

    Fuzzy settings: Select Fuzzy pinyin pairs.

    About: View DioPen Chinese IME information.
- **Samsung keypad**
  - **Samsung keypad**: Set the device to use the Samsung keyboard.

- **Settings**:
  Input language: Select languages for text input.
  XT9: Enable or disable XT9 predictive text. When enabled, the system suggests words matching your text entries, and, optionally, completes common words automatically.
  XT9 advanced settings:
  - **Word completion**: Enable or disable automatic word completion for words matching your text entries.
  - **Word completion point**: Choose the number of letters for the system to use to predict words for automatic completion.
  - **Spell correction**: Enable or disable automatic spell checking and correction.
  - **Next word prediction**: When enabled, the system predicts the next word based on common usage patterns.
  - **Auto-substitution**: When enabled, the system automatically replaces words you enter with words from the XT9 auto-substitution list.
  - **Regional correction**: When enabled, the system automatically changes the spelling of words based on norms for your locale.
  - **Recapture**: When enabled, the system re-displays matching words when you make corrections to a word inserted by the system.
  - **XT9 my words**: Add words to your XT9 predictive text dictionary.
  - **XT9 auto-substitution**: Manage the list of words the system uses for auto-substitution (Auto-substitution setting must be enabled).

  Automatic full stop: Enable or disable to insert a full stop automatically by touching the space bar twice.
  Sound on keypress: Check to play a brief sound each time you touch an on-screen keyboard key.

Auto-capitalization: Set the device to automatically capitalise the first letter after a final punctuation mark, such as a full stop, question mark, or exclamation mark.

Voice input: Enable or disable the Voice input feature. When enabled, you can choose to enter text by speaking words, using Google's network speech recognition feature.

Handwriting settings: Customise the settings for Handwriting mode, such as recognition time, pen thickness or pen colour.

Tutorial: Display the help for using Samsung keypad and XT9 predictive text.

Accessibility

Accessibility services are special features to make using the device easier for those with certain physical disabilities. Use the Accessibility settings to activate these services.

- **Accessibility**: Activate an accessibility application you have downloaded, such as Talkback or Kickback, which provide voice, melody, or vibration feedback.
- **Accessibility applications**: Enable or disable to use accessibility services.

You must activate **Accessibility** before enabling services.

  - **TalkBack**: Set the device to use the TalkBack keyboard.
- **Download accessibility scripts**: Use this option to allow or disallow applications to download accessibility scripts from Google.
- **Tap and hold delay**: Use this option to set the delay time for touch and hold.
- **Torch light**: Turn the torch light on or off.
- **Mono audio**: Enable mono sound when you listen to audio with one earbud.

- **Accessibility shortcut**: Add a shortcut to Accessibility settings on the quick menu that appears when you press and hold the Power key.

Date and time

By default, your device receives date and time information from the wireless network. When you are outside network coverage, you may want to set date and time information manually using the Date and time settings.

If the battery remains fully discharged or removed from the device, the time and date will be reset.

- **Set date**: Enter the current date (available only when the Automatic setting is disabled).
- **Set time**: Enter the current time (available only when the Automatic setting is disabled).
- **Select time zone**: Choose your local time zone (only available when the Automatic setting is disabled).
- **Use 24-hour format**: Set the format for time displays.
- **Select date format**: Set the format for date displays.

About device

View information about your device, including status, legal information, hardware and software versions, battery use, and update the device system.

Troubleshooting

Your device displays network or service error messages

- When you are in areas with weak signals or poor reception, you may lose reception. Move to another area and try again.
- You cannot access some options without a subscription. Contact your service provider for more details.

The touch screen responds slowly or improperly

If your device has a touch screen and the touch screen is not responding properly, try the following:

- Remove any protective covers from the touch screen. Protective covers may prevent the device from recognising your inputs and are not recommended for touch screen devices.
- Ensure that your hands are clean and dry when touching the touch screen.
- Restart your device to clear any temporary software bugs.
- Ensure that your device software is upgraded to the latest version.
- If the touch screen is scratched or damaged, take it to your local Samsung Service Centre.

Your device freezes or has fatal errors

If your device freezes or hangs, you may need to close programs or reset the device to regain functionality. If your device is frozen and unresponsive, press and hold the Power key for 10-15 seconds. The device will reboot automatically.

If this does not solve the problem, perform a factory data reset. Open the application list and select **Settings** → **Privacy** → **Factory data reset** → **Reset device** → **Erase everything**.

The device beeps and the battery icon is empty

Your battery is low. Recharge the battery to continue using the device.

The battery does not charge properly or the device turns off

If the battery will no longer charge completely, you need to replace it with a new battery. Take your device to your local Samsung Service Centre.

Your device is hot to the touch

When you use applications that require more power or use applications on your device for an extended period of time, your device may feel hot to the touch. This is normal and should not affect your device's lifespan or performance.

Error messages appear when launching the camera

Your Samsung device must have sufficient available memory and battery power to operate the camera application. If you receive error messages when launching the camera, try the following:

- Charge the battery.
- Free some memory by transferring files to a PC or deleting files from your device.
- Restart the device. If you are still having trouble with the camera application after trying these tips, contact a Samsung Service Centre.

Error messages appear when opening music files

Some music files may not play on your Samsung device for a variety of reasons. If you receive error messages when opening music files on your device, try the following:

- Free some memory by transferring files to a PC or deleting files from your device.

- Ensure that the music file is not Digital Rights Management (DRM)-protected. If the file is DRM-protected, ensure that you have the appropriate license or key to play the file.
- Ensure that your device supports the file type.

Another Bluetooth device is not located

- Ensure that the Bluetooth wireless feature is activated on your device.
- Ensure that the Bluetooth wireless feature is activated on the device you wish to connect to, if necessary.
- Ensure that your device and the other Bluetooth device are within the maximum Bluetooth range (10 m).

If the tips above do not solve the problem, contact a Samsung Service Centre.

A connection is not established when you connect the device to a PC

- Ensure that the USB cable you are using is compatible with your device.
- Ensure that you have the proper drivers installed and updated on your PC.

Safety precautions

To prevent injury to yourself and others or damage to your device, read all of the following information before using your device.

Warning: Prevent electric shock, fire, and explosion

Do not use damaged power cords or plugs, or loose electrical sockets

Do not touch the power cord with wet hands, or disconnect the charger by pulling on the cord

Do not bend or damage the power cord

Do not use your device while charging or touch your device with wet hands

Do not short-circuit the charger

Do not drop or cause an impact to the charger or the device

Do not charge the battery with chargers that are not approved by the manufacturer

Do not use your device during a thunderstorm

Your device may malfunction and your risk of electric shock is increased.

Handle and dispose of the device and chargers with care

- Use only Samsung-approved batteries and chargers specifically designed for your device. Incompatible chargers can cause serious injuries or damage to your device.
- Never dispose of devices in a fire. Follow all local regulations when disposing of used devices.

- Never place devices on or in heating devices, such as microwave ovens, stoves, or radiators. Batteries may explode when overheated.
- Never crush or puncture the device. Avoid exposing the device to high external pressure, which can lead to an internal short circuit and overheating.

Protect the device and chargers from damage

- Avoid exposing your device to very cold or very hot temperatures.
- Extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of your device and batteries.
- Never use a damaged charger.

Caution: Follow all safety warnings and regulations when using your device in restricted areas

Turn off your device where prohibited

Comply with all regulations that restrict the use of a mobile device in a particular area.

Do not use your device near other electronic devices

Most electronic devices use radio frequency signals. Your device may interfere with other electronic devices.

Do not use your device near a pacemaker

- Avoid using your device within a 15 cm range of a pacemaker if possible, as your device can interfere with the pacemaker.
- If you must use your device, keep at least 15 cm away from the pacemaker.
- To minimise the possible interference with a pacemaker, use your device on the opposite side of your body from the pacemaker.

Do not use your device in a hospital or near medical equipment that can be interfered with by radio frequency

If you personally use any medical equipment, contact the manufacturer of the equipment to ensure the safety of your equipment from radio frequency.

If you are using a hearing aid, contact the manufacturer for information about radio interference

Some hearing aids may be interfered with by the radio frequency of your device. Contact the manufacturer to ensure the safety of your hearing aid.

Turn off the device in potentially explosive environments

- Always comply with regulations, instructions and signs in potentially explosive environments.
- Do not use your device at refuelling points (service stations), near fuels or chemicals, and at blasting areas.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories.

Turn off your device when in an aircraft

Using your device in an aircraft is illegal. Your device may interfere with the electronic navigation instruments of the aircraft.

Electronic devices in a motor vehicle may malfunction due to the radio frequency of your device

Electronic devices in your car may malfunction due to radio frequency of your device. Contact the manufacturer for more information.

Do not use a headset while operating an automobile, motorcycle, or bicycle

- Doing so can lead to a serious accident and may be prohibited by law in some areas.
- Using a headset while walking or jogging on roads or in crosswalks can lead to a serious accident.

Comply with all safety warnings and regulations regarding mobile device usage while operating a vehicle

While driving, safely operating the vehicle is your first responsibility. Never use your mobile device while driving, if it is prohibited by law. For your safety and the safety of others, practice good common sense and remember the following tips:

- Use a hands-free device.
- Position your device within easy reach. Be able to access your wireless device without removing your eyes from the road.
- If an internet call application is available, let the person you are speaking with know you are driving. Suspend calls in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and heavy traffic can be hazardous.

- Do not take notes or look up phone numbers. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility of driving safely.
- If an internet call application is available, dial sensibly and assess the traffic. Place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call, dial only a few numbers, check the road and your mirrors, then continue.
- If an internet call application is available, do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.
- If an internet call application is available, use your device to call for help. Dial a local emergency number in the case of fire, traffic accident, or medical emergencies.
- If an internet call application is available, use your device to help others in emergencies. If you see an auto accident, a crime in progress, or a serious emergency where lives are in danger, call a local emergency number.
- If an internet call application is available, call roadside assistance or a special, non-emergency assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or another special, non-emergency number.

Proper care and use of your mobile device

Keep your device dry

- Humidity and all types of liquids may damage device parts or electronic circuits.
- Do not turn on your device if it is wet. If your device is already on, turn it off and remove the battery immediately (if the device will not turn off or you cannot remove the battery, leave it as-is). Then, dry the device with a towel and take it to a service centre.
- Liquids will change the colour of the label that indicates water damage inside the device. Water damage to your device can void your manufacturer's warranty.

Do not use or store your device in dusty, dirty areas

Dust can cause your device to malfunction.

Do not store your device on slopes

If your device falls, it can be damaged.

Do not store your device in hot or cold areas. Use your device at -20 °C to 45 °C

- Your device can explode if left inside a closed vehicle, as the inside temperature can reach up to 80 °C.
- Do not expose your device to direct sunlight for extended periods of time (such as on the dashboard of a car).
- Store the battery at -20 °C to 45 °C.

Do not store your device with such metal objects as coins, keys and necklaces

Your device may become deformed or malfunction.

Do not store your device near magnetic fields

- Your device may malfunction or the battery may discharge from exposure to magnetic fields.
- Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields.
- Do not use carrying cases or accessories with magnetic closures or allow your device to come in contact with magnetic fields for extended periods of time.

Do not store your device near or in heaters, microwaves, hot cooking equipment, or high pressure containers

- The battery may leak.
- Your device may overheat and cause a fire.

Do not drop your device or cause impacts to your device

- The screen of your device may be damaged.
- If bent or deformed, your device may be damaged or parts may malfunction.

Do not use your device or applications for a while if the device is overheated

Prolonged exposure of your skin to an overheated device may cause low temperature burn symptoms, such as red spots and pigmentation.

If your device has a camera flash or light, do not use a flash close to the eyes of people or pets

Using a flash close to the eyes may cause temporary loss of vision or damage to the eyes.

Use caution when exposed to flashing lights

- While using your device, leave some lights on in the room and do not hold the screen too close to your eyes.
- Seizures or blackouts can occur when you are exposed to flashing lights while watching videos or playing Flash-based games for extended periods. If you feel any discomfort, stop using the device immediately.

Reduce the risk of repetitive motion injuries

When you repetitively perform actions, such as pressing keys, drawing characters on a touch screen with your fingers, or playing games, you may experience occasional discomfort in your hands, neck, shoulders, or other parts of your body. When using your device for extended periods, hold the device with a relaxed grip, press the keys lightly, and take frequent breaks. If you continue to have discomfort during or after such use, stop use and see a physician.

Ensure maximum battery and charger life

- Avoid charging batteries for more than a week, as overcharging may shorten battery life.
- Over time, unused batteries will discharge and must be recharged before use.
- Disconnect chargers from power sources when not in use.

Use manufacturer-approved batteries, chargers, accessories and supplies

- Using generic batteries or chargers may shorten the life of your device or cause the device to malfunction.
- Samsung cannot be responsible for the user's safety when using accessories or supplies that are not approved by Samsung.

Do not bite or suck on the device

- Doing so may damage the device or cause explosion.
- If children use the device, make sure that they use the device properly.

When using the device:

- Speak directly into the mouthpiece.
- Avoid contact with your device's internal antenna. Touching the antenna may cause the device to transmit more radio frequency than necessary.

Protect your hearing and ears when using a headset

- Excessive exposure to loud sounds can cause hearing damage.
- Exposure to loud sounds while driving may distract your attention and cause an accident.
- Always turn the volume down before plugging the earphones into an audio source and use only the minimum volume setting necessary to hear your conversation or music.
- In dry environments, static electricity can build up in the headset. Avoid using headsets in dry environments or touch a metal object to discharge static electricity before connecting a headset to the device.

Use caution when using the device while walking or moving

Always be aware of your surroundings to avoid injury to yourself or others.

Do not carry your device in your back pockets or around your waist

You can be injured or damage the device if you fall.

Do not disassemble, modify, or repair your device

Any changes or modifications to your device can void your manufacturer's warranty. For service, take your device to a Samsung Service Centre.

Do not paint or put stickers on your device

Paint and stickers can clog moving parts and prevent proper operation. If you are allergic to paint or metal parts of the product, you may experience itching, eczema, or swelling of the skin. When this happens, stop using the product and consult your physician.

When cleaning your device:

- Wipe your device or charger with a towel or a rubber.
- Do not use chemicals or detergents.

Do not use the device if the screen is cracked or broken

Broken glass or acrylic could cause injury to your hands and face. Take the device to a Samsung Service Centre to have it repaired.

Do not use the device for anything other than its intended use

Avoid disturbing others when using the device in public

Do not allow children to use your device

Your device is not a toy. Do not allow children to play with it as they could hurt themselves and others, or damage the device.

Install mobile devices and equipment with caution

- Ensure that any mobile devices or related equipment installed in your vehicle are securely mounted.
- Avoid placing your device and accessories near or in an air bag deployment area. Improperly installed wireless equipment can cause serious injury when air bags inflate rapidly.

Allow only qualified personnel to service your device

Allowing unqualified personnel to service your device may result in damage to your device and will void your manufacturer's warranty.

Handle memory cards with care

- Do not remove a card while the device is transferring or accessing information, as this could result in loss of data and/or damage to the card or device.
- Protect cards from strong shocks, static electricity, and electrical noise from other devices.
- Do not touch gold-coloured contacts or terminals with your fingers or metal objects. If dirty, wipe the card with a soft cloth.

Keep your personal and important data safe

- While using your device, be sure to back up important data. Samsung is not responsible for data loss.
- When disposing of your device, back up all data and then reset your device to prevent misuse of your personal information.

Do not distribute copyright-protected material

Do not distribute copyright-protected material that you have recorded to others without the permission of the content owners. Doing this may violate copyright laws. The manufacturer is not liable for any legal issues caused by the user's illegal use of copyrighted material.

Specific Absorption Rate (SAR) certification information

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organisation (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg.

When carrying the product or using it while worn on the body maintain a distance of 5 mm from the body to ensure compliance with RF exposure requirements.

Disclaimer

Some content and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and/or other intellectual property laws. Such content and services are provided solely for your personal noncommercial use. You may not use any content or services in a manner that has not been authorised by the content owner or service provider. Without limiting the foregoing, unless expressly authorised by the applicable content owner or service provider, you may not modify, copy, republish, upload, post, transmit, translate, sell, create derivative works, exploit, or distribute in any manner or medium any content or services displayed through this device.

"THIRD PARTY CONTENT AND SERVICES ARE PROVIDED "AS IS." SAMSUNG DOES NOT WARRANT CONTENT OR SERVICES SO PROVIDED, EITHER EXPRESSLY OR IMPLIEDLY, FOR ANY PURPOSE. SAMSUNG EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. SAMSUNG DOES NOT GUARANTEE THE ACCURACY, VALIDITY, TIMELINESS, LEGALITY, OR COMPLETENESS OF ANY CONTENT OR SERVICE MADE AVAILABLE THROUGH THIS DEVICE AND UNDER NO CIRCUMSTANCES, INCLUDING NEGLIGENCE, SHALL SAMSUNG BE LIABLE, WHETHER IN CONTRACT OR TORT, FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, ATTORNEY FEES, EXPENSES, OR ANY OTHER DAMAGES ARISING OUT OF, OR IN CONNECTION WITH, ANY INFORMATION CONTAINED IN, OR AS A RESULT OF THE USE OF ANY CONTENT OR SERVICE BY YOU OR ANY THIRD PARTY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES."

Third party services may be terminated or interrupted at any time, and Samsung makes no representation or warranty that any content or service will remain available for any period of time. Content and services are transmitted by third parties by means of networks and transmission facilities over which Samsung has no control. Without limiting the generality of this disclaimer, Samsung expressly disclaims any responsibility or liability for any interruption or suspension of any content or service made available through this device.

Samsung is neither responsible nor liable for customer service related to the content and services. Any question or request for service relating to the content or services should be made directly to the respective content and service providers.

Some of the contents in this manual may differ from your device depending on the software of the device or your service provider.

To install Kies (PC Sync) Kies

1. Download the latest version of Kies from the Samsung website (**www.samsung.com/kies**) and install it on your PC.
2. Using a USB cable, connect your device to your PC. Samsung Kies will launch automatically.
   Refer to the Kies help for more information.